



OpenVox Communication Co.,Ltd.



SWG20XX-4S Wireless Gateways

User Manual

Version 1.0



OpenVox Communication Co.,Ltd.

Address: Room 624, 6/F, Tsinghua Information Port, Book Building,
Qingxiang Road, Longhua Street, Longhua District, Shenzhen,
Guangdong, China 518109

Tel: +86-755-66630978, 82535461, 82535362

Business Contact: sales@openvox.cn

Technical Support: support@openvox.cn

Business Hours: 09:00-18:00(GMT+8) from Monday to Friday

URL: www.openvoxtech.com

Thank You for Choosing OpenVox Products!

Copyright

Copyright[©] 2020 OpenVox Inc. All rights reserved. No part of this document may be reproduced without prior written permission.

Confidentiality

Information contained herein is of a highly sensitive nature and is confidential and proprietary to OpenVox Inc. No part may be distributed, reproduced or disclosed orally or in written form to any party other than the direct recipients without the express written consent of OpenVox Inc.

Disclaimer

OpenVox Inc. reserves the right to modify the design, characteristics, and products at any time without notification or obligation and shall not be held liable for any error or damage of any kind resulting from the use of this document.

OpenVox has made every effort to ensure that the information contained in this document is accurate and complete; however, the contents of this document are subject to revision without notice. Please contact OpenVox to ensure you have the latest version of this document.

Statement

This document applies to all SWG-20XX-4S series gateways, including GSM/LTE. Different types of gateways may have functional differences. For details, please contact OpenVox sales or technical support.

Trademarks

All other trademarks mentioned in this document are the property of their respective owners.

Revision History

Version	Date	Detail
1.0	2019/12/24	Initial

Contents

1. Overview	4
1.1 What is SWG20XX-4S Series Wireless Gateways?	4
1.2 Product Introduction	4
1.3 Application	6
1.3.1 LCD, Buttons and direction of sim card	6
1.3.2 Multifunction button	8
1.3.3 Console	8
1.4 Main Features	9
1.5 Physical Information	11
1.6 Software	12
2. System	13
2.1 Status	13
2.2 Time	15
2.3 Login Settings	16
2.4 General	17
2.5 Tools and Information	18
2.6 Setting Wizard	21
3. Module	22
3.1 Module Settings	22
3.2 Call Forwarding	28
3.3 Call Waiting	29
3.4 DTMF	30
3.5 Toolkit	32
3.6 Module Update	33
3.7 Call and SMS Limit	33
3.8 the strategy of switching card	39

4.1 VOIP Endpoints	41
4.1.1 Add New SIP Endpoint.....	41
4.1.2 Add New IAX2 Endpoint.....	50
4.2 Batch SIP Endpoints	55
4.3 Advanced SIP Settings	56
4.4 Advanced IAX2 Settings	64
4.5 SIP Account Security	71
5. Routing	73
5.1 Call Routing Rules	73
5.2 Groups	77
5.3 Batch Creating rules	77
5.4 MNP Settings	79
5.5 Routing Blacklist	79
6. SMS	80
6.1 General	80
6.2 SMS Sender	86
6.3 SMS Inbox.....	86
6.4 SMS Outbox	87
6.5 SMS Forwarding	88
7. Network	89
7.1 LAN Settings	89
7.2 WAN Settings	90
7.3 VPN Settings	91
7.4 DDNS Settings	91
7.5 Toolkit	92
7.6 Firewall Settings	93
7.7 Security Rules	94
7.8 SIP Capture	95

8. Advances	96
8.1 Asterisk API	96
8.2 Asterisk CLI	98
8.3 Asterisk File Editor	99
8.4 Internet	99
8.5 Cloud Management	100
8.6 Balance	101
8.7 Phone Number	102
9. Logs	103

1. Overview

1.1 What is SWG20XX-4S Series Wireless Gateways?

OpenVox SWG20XX-4S series wireless gateways include SWG-2016-4S G/L and SWG-2032-4S G/L. They can bring you excellent HD voice service with multiple codecs, including G.711U, G.711A, GSM, G.722, G.726, G.729, and also flexible SMS service with multiple SMS API. The SWG-2016/32-4S series gateways are perfect compatible with Asterisk, 3CX, FreePBX, FreeSWITCH SIP server and VOS VoIP system platform. It can provides users with more diverse telecommunications access methods and helps users reduce communication costs.

The SWG20XX-4S series of wireless gateways feature a powerful Intel 4-core CPU. And with a unique LCD screen design, you can see the status of each channel on this screen clearly. Through the buttons next to the display, you can easily implement a variety of functions such as viewing gateway system related information, configuring network information, restarting the gateway or restoring factory settings and so on, without logging in to the WEB page.

1.2 Product Introduction

The SWG-2016/32-4S series gateways are available in a variety of models, and each model supports a different number of ports and frequency bands. The following table shows:

Model	Module	Ports	Network Interface	Band	USB	TF	Console
SWG2016-4S	LTE	64	2	China/India LTE FDD: B1/B3/B5/B8 LTE TDD: B38/B38/B40/B41	1	1	1

				WCDMA: B1/B8 TD-SCDMA: B34/B39 CDMA: BC0 GSM: 900/1800MHz Europe/Middle East/Africa/ Korea/Thailand LTE FDD: B1/B3/B5/B7/B8/B20 LTE TDD: B38/B40/B41 WCDMA: B1/B5/B8 GSM: B3/B8			
SWG2032-4S	GSM	64		GSM: 850/900/1800/1900MHz	1	1	1

				LTE TDD: B38/B40/B41 WCDMA: B1/B5/B8 GSM: B3/B8			
GSM	128			GSM: 850/900/1800/1900MHz			

1.3 Application

1.3.1 LCD, Buttons and direction of sim card

The image on the right side of card slots indicates the card insertion direction.

Among the four card slots of each port, the sim card ships inserted in slot 1 and 2 face upward, and the chips inserted in 3 and 4 slots face down.

The black numbers indicate the first few slots, and the blue numbers indicate the first few cards in the slot..

LED Indicator/Icon/ Buttons	Color/ Icon	Status
Display Icon		Module Initiating, Disable
		No SIM Card
		Searching for Signal

		One grid Signal
		Two grid Signal
		Three grid Signal
		Four grid Signal
		Five grid Signal
		Worst Signal Quality During a Call
		Medium Signal Quality During a Call
		Best Signal Quality During a Call
Network Status LED	Green and Flash	Network Connected
PWR	Always Green	Power on
POWER Button	OFF	Power down
	ON	Power on
RST Button	--	Press and hold the RST button for 3-5 seconds. The display jumps to the "System"

		Booting" page to restart the system.
--	--	--------------------------------------

1.3.2 Multifunction button

1. **【▲】:** Press this key to flip up
2. **【OK】:**
 - Press this key in the signal interface - Enter the menu;
 - Press this key in the menu interface – Confirm;
 - Press this key if it is Non-signal interface and there is no return option in the current interface - Back。
3. **【▼】:** Press this key to flip down。
4. Press any key in the signal interface to enter the menu interface。
5. If no button is operated within 20S, return to the main interface。

1.3.3 Console


To ensure easy maintenance, SWG-2016/32 series gateway devices provide a serial port with a baud rate of 115200 bps. Users can connect to the computer through RJ45 to USB cable for maintenance related configuration.

Login device:

1. Prepare the following serial cable (baud rate: 115200bps).



2. Connect the USB port of the serial cable to the PC; connect the RJ45 port to the console port of the device.
3. Configure the login software.



After the above configuration, click "Open" to enter the device's background page.

Use the same login name and password as SSH to enter the system.

1.4 Main Features

VoIP Characters

- Support SIP, IAX2 Protocol
- Add, Modify & Delete SIP/IAX2 Trunk

- SIP/IAX2 Registration with Domain
- SIP V2.0 RFC3261 Compliance
- DTMF Mode: RFC2833/Inband/SIP Info
- Multiple SIP/IAX2 Registrations modes
- Abundant Codecs: G.711A, G.711U, G.729, G.722, G.726, GSM

Network

- IPv4, UDP/TCP, DHCP, TELNET, HTTP/HTTPS, TFTP
- PPTP VPN
- HTTP/SSH (Optical Telnet)
- Ping & Traceroute Command on the Web
- Simple Security Strategy: white list, black list, security rules

Management

- Simple and convenient configuration via Web GUI
- Support maintenance and configuration by SSH
- Support configuration files backup and upload
- Support Chinese and English page
- Firmware Update by HTTP
- Support Web and SSH login password modification
- Restore Factory Settings
- CDR (More than 200,000 Lines CDRs Storage Locally)
- System log
- SIP/IAX2 log
- TCP and SIP capture

System Features

- Combine Different SIP/IAX2 Trunk into Group
- CLID Display & Hide (Need operators' support)
- Random call interval
- Call Duration Limitation

-
- Single Call Duration Limitation
 - Real Open API Protocol (based on Asterisk)
 - Support DISA
 - SMSC/SMS/USSD
 - PIN Identification
 - Optional Voice Codec
 - Ports Group Management
 - SMS Remotely Controlling Gateway
 - SMS Bulk Transceiver, Sent to Email and Automatically Resend
 - SMS Coding/Detecting Automatically Identification
 - SMS Forwarding and Quick Reply
 - USSD transceiver
 - Outbound
 - Automatically Reboot
 - Support MMP
 - Support for custom scripts, dial plans
 - Support OpenVox cloud manage

1.5 Physical Information

- LAN port:1
 - WAN port: 1
 - Console: 1
 - USB Interface: 1
 - TF Interface: 1
 - LCD dimension:2.4"
 - LCD resolution ratio: 240*400
 - SIM Cards: hot-swap
 - Operation Temperature: 0~40°C
-

- Operation humidity:10% ~ 90% non-condensing
- Storage Temperature: -20~70°C

1.6 Software

LAN:

- Default IP: 172.16.98.1
- Username: admin
- Password: admin

For the first time, you can access SWG-2008 by using default IP 172.16.98.1; if you use the default login name and password, you will be prompted to change the password each time you log in. If you have modified it, you will not be prompted.

If you use WAN to connect the device, the WAN port uses DHCP by default. Please use the display to view the IP address assigned by the WAN to access the device. Use the default login name and password—admin/admin to log in to the device.

2. System

2.1 Status

On the “Status” page, you will find the information of all Modules, SIP, IAX2, Routing and the Network.

Figure 2-1-1 System Status

Module Information												
Port	Slot	Type	Signal	Band	BER	Carrier	Registration Status	PDD(s)	ACD(s)	ASR(%)	Module Status	Remain Time Times
1		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
2		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
3		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
4		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
5		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
6		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
7		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
8		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
9		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
10		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
11		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
12		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
13		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
14		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
15		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
16		CDMA			-1		Undetected SIM Card	0	0	0		No Limit Limited
17	1	LTE		LTE	-1	CHINA MOBILE	Registered (Home network)	0	0	0	READY	No Limit Limited
18		LTE			-1		Undetected SIM Card	0	0	0		No Limit Limited
19	3	GSM			0		Undetected SIM Card	0	0	0		No Limit Limited
20		GSM			-1		Undetected SIM Card	0	0	0		No Limit Limited
21		GSM			-1		Undetected SIM Card	0	0	0		No Limit Limited
22		GSM			-1		Undetected SIM Card	0	0	0		No Limit Limited
23		LTE			-1		Undetected SIM Card	0	0	0		No Limit Limited
24		LTE			-1		Undetected SIM Card	0	0	0		No Limit Limited

Table 2-1-1 Description of System Status

Option	Definition
Port	Number of each ports. GSM port starts with "gsm-", Such as: gsm-19; 4 port starts with "lte-", Such as: lte-17.
Signal	Display the signal strength of each channels of gateway.
Band	GSM/ LTE

BER	Bit Error Rate.
Carrier	Display the network carrier of current SIM card.
Registration Status	Indicates the registration status of current module.
PDD	Post Dial Delay (PDD) is the time from the point at which the final dialed digit is sent until they hear a ringtone or other in-band message. In the case where the originating network needs to play a notification before the call is completed, the definition of the PDD excludes the duration of such notification.
ACD	The Average Call Duration (ACD) is calculated by taking the sum of billable seconds (bill sec) of answered calls and dividing it by the number of these answered calls.
ASR	Answer Seizure Ratio is a measure of network quality. Its calculated by taking the number of successfully answered calls and dividing by the total number of attempted calls. Since busy signals and other rejections by the called number count as call failures, the ASR value can depend on user behavior.
Module Status	Display the status of the port. "A space" means the port is unavailable. "INIT" means registering and "READY" means the port is available.
Remain Time	Multiply this value by the step size as the limit call time.

2.2 Time

Table 2-2-1 Definition of Time Settings

Options	Definition
System Time	Your gateway system time.
Time Zone	The world time zone: Please select the one which is the same or the closest as your city.
POSIX TZ String	Posix time zone strings.
NTP Server 1	Time server domain or hostname. For example: [time.asia.apple.com].
NTP Server 2	The first reserved NTP server. For example: [time.windows.com].
NTP Server 3	The second reserved NTP server. For example: [time.nist.gov].
Automatic Sync from NTP	Whether to enable automatic sync time from NTP. On (enable), OFF (disable).
Sync from NTP	Sync time from NTP server.
Sync from Client	Sync time from local machine.

For example, you can configure like this:

Figure 2-2-1 Time Setting

Time Settings	
System Time:	2019-4-1 12:25:55
Time Zone:	Chongqing
POSIX TZ String:	CST-8
NTP Server 1:	pool.ntp.org
NTP Server 2:	64.236.96.53
NTP Server 3:	ntp1.aliyun.com
Auto-Sync from NTP:	ON

Save Data Sync from NTP Sync from Client

You can synchronize the gateway time in different ways: Sync from NTP or Sync from Client by pressing different buttons.

2.3 Login Settings

The new gateway has no administration privileges, all you can do is reset a username and password to manage your gateway. The username and password have all the permissions to operate the gateway. You can modify “Web Login Settings” and “SSH Login Settings”. If you have changed these settings, you don’t need to log out, just rewriting your new username and password will be OK. Also, you can specify the web server port number. Normally, the default web login mode is "http and https." For security, you can switch to “only https”.

Table 2-3-1 Definition of Login Settings

Options	Definition
User Name	Define your username to manage your gateway. Allowed characters "-_<>@&0-9a-zA-Z". Length: 1-32 characters.
Password	Define your password to manage your gateway. Allowed

	characters "-_<>A-Z". Length: 1-32 characters.
Confirm Password	Please input the same password as 'Password' above.
Login Mode	http and https: You can access gateway via link: http://gatewayIP or https://gatewayIP https: You can only access gateway via link: https://gatewayIP
Port	Specify the web server port number.

Figure 2-3-1 Login Settings

The screenshot displays the 'Web Login Settings' and 'SSH Login Settings' sections of the configuration interface. In the 'Web Login Settings' section, the 'User Name' field contains 'admin123', and the 'Login Mode' dropdown is set to 'http and https'. In the 'SSH Login Settings' section, the 'Enable' switch is turned 'ON', and the 'User Name' and 'Password' fields both contain 'super'.

2.4 General

You can choose different languages for your system. If you want to change the language, you can switch “Advanced” on, then “Download” your current language package. After that, you can modify the package with the language you need. Then upload your modified packages, “Choose File” and “Add”. For example:

Figure 2-4-1 Language Settings

The screenshot shows the 'Language Settings' interface. It includes fields for 'Language' (set to English), 'Advanced' (set to ON), 'Language Debug' (options: TURN ON, TURN OFF), and download/upload functions for language packages. There are also buttons for 'Delete' and 'Add New Language'.

If you switch it on, you can manage your gateway to reboot automatically as you like.

There are four reboot types for you to choose, "By Day, By Week, By Month or By Running Time.

Figure 2-4-2 Reboot Type

The screenshot shows the 'Scheduled Reboot' settings. It has an 'Enable' field set to OFF, a 'Reboot Type' dropdown set to 'By Running Time', and a 'Running Time' field showing 'Hour: 0'.

You can set this enable if you use your system frequently, it can help your system work more efficiently.

2.5 Tools and Information

Reboot Tools

You can choose system reboot or asterisk reboot separately. The new version of the gateway retains two file systems. Clicking "System Switch" will reboot the system and switch to another file system.

Figure 2-5-1 Reboot Tools

The screenshot shows the 'Reboot Tools' page. It displays three options: 'Reboot Tools' (warning: all calls will be dropped), 'System Reboot' (button), 'Asterisk Reboot' (button), and 'System Switch' (button). A central message box asks if the user is sure about rebooting, stating they will lose all data in memory.

If you press "OK", the system will restart and the current call will be hung up. The same as the Asterisk Reboot.

Update Firmware

We offer 2 kinds of update types for you, you can choose System Update or System Online Update.

Figure 2-5-2 Update Firmware



Upload and Backup Configuration

If you want to update your system and remain your previous configuration, you can backup configuration first. Then you can upload configuration directly. It will be very convenient for you.

Figure 2-5-3 Upload and Backup Configuration



Voice Record

Select a module to record the voice, the maximum duration of the recording is 3 minutes. When the recording time exceeds 3 minutes, the recording file will be automatically downloaded.

Figure 2-5-4 Voice Record




Restore Configuration

Sometimes there is something wrong with your gateway that you don't know how to solve it. Mostly you can select factory reset, you just need to press a button and your

gateway will be reset to the factory status.

Figure 2-5-5 Restore Configuration



System Information

On the “Information” page, there shows some basic information about the gateway. You can see software and hardware version, storage usage, memory usage and some other useful information.


Figure 2-5-6 System Information

产品型号:	
GSM 模块模式:	GSM: 850/900/1800/1900MHz
CDMA 模块模式:	CDMA 2000: 800MHz
LTE 模块模式:	LTE FDD: B1/B3/B5/B8 LTE TDD: B38/B39/B40/B41 TD-SCDMA: B34/B39 CDMA: BC0 WCDMA: 900/2100MHz GSM: 900/1800MHz
软件版本:	2.1.5
硬件版本:	2.0
槽位:	1
存储占用:	70.7M/487.9M (16%)
内存占用:	29.9788 % 清理内存
建立时间:	2019-05-31 16:20:00
联系地址:	中国深圳市龙华区宝能科技园6栋A座10楼
电话:	+86-755-82535461
传真:	+86-755-83823074
邮箱:	support@openvox.cn
网站:	http://openvox.com.cn
系统重启次数:	72
系统时间:	2019-8-27 16:21:18
系统运行时长:	0 days 06:34:42

2.6 Setting Wizard

According to the boot, you can change the password, set the time, network, and create SIP terminals and routes quickly.

Figure 2-6-1 Setting Wizard



3. Module

You can see the information of SIM card on this page.

3.1 Module Settings

Figure 3-1-1 Module Settings

端口	类型	运营商	注册状态	模块状态	操作
1	CDMA		Undetected SIM Card		 
2	CDMA		Undetected SIM Card		 
3	CDMA		Undetected SIM Card		 
4	CDMA		Undetected SIM Card		 
5	CDMA		Undetected SIM Card		 
6	CDMA		Undetected SIM Card		 
7	CDMA		Undetected SIM Card		 
8	CDMA		Undetected SIM Card		 
9	CDMA		Undetected SIM Card		 
10	CDMA	CHINA TELECOM	Registered (Home network)	READY	 
11	CDMA		Undetected SIM Card		 
12	CDMA		Undetected SIM Card		 
13	CDMA		Undetected SIM Card		 
14	CDMA		Undetected SIM Card		 
15	CDMA		Undetected SIM Card		 
16	CDMA		Undetected SIM Card		 
17	LTE	CHINA MOBILE	Registered (Home network)	READY	 
18	LTE		Undetected SIM Card		 
19	GSM	CHINA MOBILE	Registered (Home network)	READY	 
20	GSM		Undetected SIM Card		 
21	GSM		Undetected SIM Card		 
22	GSM		Undetected SIM Card		 
23	LTE		Undetected SIM Card		 
24	LTE		Undetected SIM Card		 

On this page, you can see the information of the module status, click the  button to configure the port.

Figure 3-1-2 Port Configuration




Port gsm-1.1

Name:	[Input Field]
Speaker Volume:	50
Microphone Volume:	8
Dial Prefix:	[Input Field]
Pin Code:	[Input Field] <input type="checkbox"/> On
Custom AT commands when start:	
STK flag:	[OFF]
CLIR:	[OFF]
SMS Center Number:	[Modify]
Band:	All Band(850/900/1800/1900MHz)
SIM IMSI:	[Input Field]
Module IMEI:	[Modify]
Module Revision:	[Input Field]
Carrier:	[Input Field]
Bind Carrier:	Auto <input type="button" value="List Carrier"/>
Signal:	-1
BER:	-1
Status:	[Input Field]
GSM Voice Codec:	ERROR
CLCC:	ON <input type="checkbox"/>
AT Timeout:	10 s

▶ Save To Other Ports

You can choose different bands in the options.

Figure 3-1-3 Band binding



If you have set your Pin Code, you can check on like this:

Figure 3-1-4 PIN Code Application

Pin Code:	123456	<input checked="" type="checkbox"/> On
-----------	--------	--


Then enter the password and the system will recognize the number of the SIM card.

It can help you prevent the SIM card from being stolen and increase the safety factor.

If you want to hide your number when you call out, you can just switch CLIR "ON" (Of course you need your operator's support).

Figure 3-1-5 CLIR Application

OpenVox GSM/3G Gateway supports optional GSM voice codec. For more details, you can see the picture below:

Figure 3-1-6 GSM Voice Codec

IMEI Modification

We also provide IMEI automatically modified performance.

Figure 3-1-7 Automatic IMEI modification

If you want to modify the IMEI number, log in to the gateway to modify the IP address as follows. Input <http://gatewayIP/cgi-bin/php/gsm-autoimei.php> in your browser. Then log in to the web page and you will see the setting as “Enable” as “ON” as shown below. Otherwise, the IMEI number cannot be modified.

Figure 3-1-8 IMEI Modification

▼ Automatic Change IMEI

Port:	<input type="checkbox"/> lte-17 <input type="checkbox"/> gsm-21 <input type="checkbox"/> All	<input type="checkbox"/> lte-18 <input type="checkbox"/> gsm-22	<input type="checkbox"/> gsm-19 <input type="checkbox"/> lte-23	<input type="checkbox"/> gsm-20 <input type="checkbox"/> lte-24
Enable:	<input type="radio"/> OFF			
Interval:	1800 Second			
Immediately:	<input type="checkbox"/> modify IMEI immediately			
Force:	<input checked="" type="checkbox"/> Modify IMEI no matter whether the channel state is ready or not.			

► Auto-IMEI Advanced

You can choose to modify one , more ports or all ports, and you can set the automatic modification interval by filling in the required time.

Figure 3-1-9 Time Interval

Interval:	1800	Second
-----------	------	--------

If you select "Modify IMEI now", the changes will take effect immediately. If you select "Force", the system will hang up the current call and modify the IMEI.

Click the button **▼ Auto-IMEI Advanced** to set it. There are two ways to modify the IMEI: manual modification or automatic generation.

Figure 3-1-10 Advanced Setting


▼ Auto-IMEI Advanced

IMEI Number Setting	TAC(6 digit)	FAC(2 digit)	SNR(6 digit)	SP(1 digit)	Current IMEI	Action
Set to All	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="button" value="Autogeneration"/>	None	<input type="button" value="Set to All"/>
gsm-1.1	35xxxx	0x	xxxxxx	<input type="button" value="Autogeneration"/>	352840039592814	<input type="button" value="Manual"/>
gsm-1.2	35xxxx	0x	xxxxxx	<input type="button" value="Autogeneration"/>	352794018702565	<input type="button" value="Manual"/>
gsm-1.3	35xxxx	0x	xxxxxx	<input type="button" value="Autogeneration"/>	357720013455078	<input type="button" value="Manual"/>
gsm-1.4	35xxxx	0x	xxxxxx	<input type="button" value="Autogeneration"/>	358415039164809	<input type="button" value="Manual"/>
lte-2.5	35xxxx	0x	xxxxxx	<input type="button" value="Autogeneration"/>		<input type="button" value="Manual"/>
lte-2.6	35xxxx	0x	xxxxxx	<input type="button" value="Autogeneration"/>	359472054874001	<input type="button" value="Manual"/>
lte-2.7	35xxxx	0x	xxxxxx	<input type="button" value="Autogeneration"/>	352018070983487	<input type="button" value="Manual"/>
lte-2.8	35xxxx	0x	xxxxxx	<input type="button" value="Autogeneration"/>	867732033402132	<input type="button" value="Manual"/>

As you can see, each port is set to any number. "X" means any number from 0-9. All you have to do is fill in all the lines and click "Set All". Click "Save", the current IMEI will change, this is automatically generated.

If you want to set the IMEI to a specific value, click on “Modify” and enter a new IMEI as required.

Figure 3-1-11 Manually set IMEI



After the configuration is completed, click "Back Home" to return to the gateway interface.


Table 3-1-1 Definition of Module Settings

Options	Definition
Name	The alias of the each port. Input name without space here. Allowed characters: "-_<>@-9a-zA-Z".Length: 1-32 characters.
Speaker Volume	The range of the speaker volume level is 0-100. This will adjust the loud speaker volume level by an AT command.
Microphone Volume	The range of the microphone volume is: 0-15. This will change the microphone volume level by an AT command
Dial Prefix	The number prefix of the outbound call through the GSM channel.
PIN Code	Personal identification numbers of SIM card. PIN code can be modified to prevent SIM card from being stolen.
Custom AT commands when start	Use “ ” to split AT command when user use custom AT commands to start system.

CLIR	Caller ID restriction, this function is used to hide the caller ID of the SIM card number. The gateway will add '#31#' in front of the mobile number. This function must be operated by a professional operator.
SMS Center Number	Your SMS center number of your local carrier.
Module IMEI	Press the Modify button to automatically modify.


Save settings to other ports:

Figure 3-1-12 Save to port



Your call status will be displayed on the main screen.

Figure 3-1-13 Module Information



3.2 Call Forwarding

Sometimes it's not convenient for you to answer the call. If you don't want to lose some important calls, you can choose call forwarding. There are different kinds of call types for you to choose, Such as call forwarding unconditional, call forwarding no reply, call forwarding busy and call forward on not reachable. If you want to cancel the call forwarding settings, you can choose to cancel all.

Figure 3-2-1 Call Forwarding

<input type="checkbox"/>	Port	Select	Call Type	Call Number	Status
<input type="checkbox"/>	lte-17	<input type="radio"/>	Call Forwarding Unconditional	<input type="text"/>	
		<input type="radio"/>	Call Forwarding No Reply	<input type="text"/>	
		<input type="radio"/>	Call Forwarding Busy	<input type="text"/>	
		<input type="radio"/>	Call Forward on Not Reachable	<input type="text"/>	
		<input type="radio"/>	Cancel All	<input type="text"/>	
<input type="checkbox"/>	lte-18	<input type="radio"/>	Call Forwarding Unconditional	<input type="text"/>	
		<input type="radio"/>	Call Forwarding No Reply	<input type="text"/>	
		<input type="radio"/>	Call Forwarding Busy	<input type="text"/>	
		<input type="radio"/>	Call Forward on Not Reachable	<input type="text"/>	
		<input type="radio"/>	Cancel All	<input type="text"/>	
<input type="checkbox"/>	gsm-19	<input type="radio"/>	Call Forwarding Unconditional	<input type="text"/>	
		<input type="radio"/>	Call Forwarding No Reply	<input type="text"/>	
		<input type="radio"/>	Call Forwarding Busy	<input type="text"/>	
		<input type="radio"/>	Call Forward on Not Reachable	<input type="text"/>	
		<input type="radio"/>	Cancel All	<input type="text"/>	
<input type="checkbox"/>	gsm-20	<input type="radio"/>	Call Forwarding Unconditional	<input type="text"/>	
		<input type="radio"/>	Call Forwarding No Reply	<input type="text"/>	
		<input type="radio"/>	Call Forwarding Busy	<input type="text"/>	
		<input type="radio"/>	Call Forward on Not Reachable	<input type="text"/>	
		<input type="radio"/>	Cancel All	<input type="text"/>	
<input type="checkbox"/>	gsm-21	<input type="radio"/>	Call Forwarding Unconditional	<input type="text"/>	
		<input type="radio"/>	Call Forwarding No Reply	<input type="text"/>	
		<input type="radio"/>	Call Forwarding Busy	<input type="text"/>	
		<input type="radio"/>	Call Forward on Not Reachable	<input type="text"/>	
		<input type="radio"/>	Cancel All	<input type="text"/>	
<input type="checkbox"/>	gsm-22	<input type="radio"/>	Call Forwarding Unconditional	<input type="text"/>	
		<input type="radio"/>	Call Forwarding No Reply	<input type="text"/>	
		<input type="radio"/>	Call Forwarding Busy	<input type="text"/>	
		<input type="radio"/>	Call Forward on Not Reachable	<input type="text"/>	
		<input type="radio"/>	Cancel All	<input type="text"/>	
<input type="checkbox"/>	lte-23	<input type="radio"/>	Call Forwarding Unconditional	<input type="text"/>	
		<input type="radio"/>	Call Forwarding No Reply	<input type="text"/>	
		<input type="radio"/>	Call Forwarding Busy	<input type="text"/>	
		<input type="radio"/>	Call Forward on Not Reachable	<input type="text"/>	
		<input type="radio"/>	Cancel All	<input type="text"/>	
<input type="checkbox"/>	lte-24	<input type="radio"/>	Call Forwarding Unconditional	<input type="text"/>	
		<input type="radio"/>	Call Forwarding No Reply	<input type="text"/>	
		<input type="radio"/>	Call Forwarding Busy	<input type="text"/>	
		<input type="radio"/>	Call Forward on Not Reachable	<input type="text"/>	
		<input type="radio"/>	Cancel All	<input type="text"/>	

3.3 Call Waiting

You can switch the Call Waiting Function of the SIM card on/off in the port on this page.

Figure 3-3-1 Call Waiting

	端口	ON OFF (呼叫等待功能)	状态
	Ite-17	ON OFF	
	Ite-18	ON OFF	
	gsm-19	ON OFF	
	gsm-20	ON OFF	
	gsm-21	ON OFF	
	gsm-22	ON OFF	
	Ite-23	ON OFF	
	Ite-24	ON OFF	

Table 3-3-1 Definition of Call Waiting

Options	Definition
Switch on call waiting	Choose the port you want to set, switch to "On" and click the "Settings" button.
Switch off call waiting	Choose the port you want to set, switch to "Off" and click the "Settings" button.
Status	It will display the results of your execution.
Settings	Used to switch the call waiting function on or off.
Query	Used to query the status of call waiting, observe whether the port that sets the call waiting is open or closed.

3.4 DTMF

You can do some DTMF Detection Settings if you choose “MODULE → DTMF”.

Figure 3-4-1 DTMF Detection Settings

DTMF Detection Settings	
DTMF Detect Flag:	<input checked="" type="checkbox"/> ON
Reference Value:	Custom ▾
Relax DTMF Normal Twist:	6.31 8.00dB
Relax DTMF Reverse Twist:	3.98 5.99dB
DTMF Relative Peak Row:	6.3 7.99dB
DTMF Relative Peak Col:	6.3 7.99dB
DTMF Hits Begin:	2
DTMF Misses End:	3

Notice: You don't have to modify these settings if you don't have special need. You can just choose "Default".

Table 3-4-1 Definition of DTMF Detection Settings

Options	Definition
DTMF Normal Twist and Reverse Twist	It is the power difference between the row and the column energies. Normal Twist is where the Column energy is greater than the Row energy. Reverse Twist is where the Row energy is greater.
DTMF Relative Peak Row	The smaller the value, the easier the detection. If you lost some numbers, you can try to put the value down. The adjustment range is 0.02 at a time.
DTMF Relative Peak Col	The smaller the value, the easier the detection. If you lost some numbers, you can try to put the value down. The adjustment range is 0.1 at a time.
DTMF Hits Begin	Simple match value, choose 2 or 3.
DTMF Misses End	The time interval between the two numbers you entered. Adjust the speed of input. The smaller value represents the shorter intervals.

3.5 Toolkit

You can get USSD information, send AT command or check the number of this module. The AT command is very helpful for you when debugging a module.

Figure 3-5-1 Function Options

Function:		
Action:		
Port	Input	Output
gsm-1.1		
gsm-1.2		
gsm-1.3		
gsm-1.4		
Ite-2.5		
Ite-2.6		
Ite-2.7		
Ite-2.8		

Table 3-5-1 Description of Definition of Functions

Options	Definition
Get USSD	Enter a specific USSD number (For example, *142# to check your SIM card's balance. This USSD number is might be different from different carriers) to get the USSD information. The gateway will try to get by AT commands.
AT Command	To perform some specific AT commands. It is useful when you have a debug of the modem. For example, perform [AT+CSQ] to check what signal qualify it is. In AT commands, there is no difference between "a" and "A" (case insensitive).
Check Number	Enter a known number (like your mobile phone number) to check what number it is of the SIM card. Click "Execute", then the gateway will dial to the number you already input. It only rings for one time and hangs up at once. Not generating

	telephone charge during this procedure.
--	---

If you want to send an AT command, enter the command, select a port first and then select "Copy to selected", and finally click "Execute".

Figure 3-5-2 AT Command Example

Function: Send AT Command ▾				
Action:	AT+CSQ	<input type="button" value="Copy to Selected"/>	<input type="button" value="Clear All"/>	<input type="button" value="Execute"/>
Port	Input			
<input checked="" type="checkbox"/> gsm-1.1	AT+CSQ			
<input checked="" type="checkbox"/> gsm-1.2	AT+CSQ			
<input type="checkbox"/> gsm-1.3				
<input type="checkbox"/> gsm-1.4				
<input type="checkbox"/> lte-2.5				
<input type="checkbox"/> lte-2.6				
<input type="checkbox"/> lte-2.7				
<input type="checkbox"/> lte-2.8				

3.6 Module Update

You can update the module version or update the microcontroller by yourself on this page.

Figure 3-6-1 Module Update

模块升级				
端口:	<input type="checkbox"/> cdma-1 <input type="checkbox"/> cdma-5 <input type="checkbox"/> cdma-9 <input type="checkbox"/> cdma-13 <input type="checkbox"/> lte-17 <input type="checkbox"/> gsm-21 <input type="checkbox"/> 全选			
模块升级文件:		<input type="button" value="选择文件"/> 未选择任何文件		<input type="button" value="升级"/>
MCU升级				
端口:	<input type="checkbox"/> cdma-1 & cdma-2 <input type="checkbox"/> cdma-9 & cdma-10 <input type="checkbox"/> lte-17 & lte-18 <input type="checkbox"/> 全选			
MCU升级文件:		<input type="button" value="选择文件"/> 未选择任何文件		<input type="button" value="升级"/>

3.7 Call and SMS Limit

Click the edit button to set call restrictions, lock cards, and SMS restrictions. You can also view statistics on call/sms sent here.

Figure 3-7-1 Call and SMS Limit

Batch Unlimit

Port	Card 1	Card 2	Card 3	Card 4	Actions
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					

Batch SMS Unlimit

Port	Card 1	Card 2	Card 3	Card 4	Actions
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					

Call Limit

You can limit the number of daily calls, number of days connected, and number of hours of calls for the selected channel.

Figure 3-7-2 Call Limit

Call Limit (gsm-1.1)	
Call Limit Switch:	<input checked="" type="checkbox"/> ON
Limit Daily Call Times:	<input type="text"/> 0
Limit Daily Answer Times:	<input type="text"/> 0
Limit Hour Call Times:	<input type="text"/> 0

Call Limit Time

Now we offer you two types of call duration limit, you can choose “Single Call Duration Limit” or “Call Duration Limitation” to control your calling time.

This will limit the time of each call. First you need to switch “Enable” on, then you can set “Step” and “Single Call Duration Limitation” any digits you want. When you make a call through this port, your calling time will be limited.

Single Call Duration Limitation: If your calling time exceeds the set value, the system will hang up the call. Multiplying the step size by a single call time is to allow a single call duration.

Figure 3-7-3 Single Settings

Call Limit Time	
Call Time Limit Switch:	<input checked="" type="checkbox"/> ON
Step:	60
Second	
Enable Single Call Duration Limit:	<input checked="" type="checkbox"/> ON
Single Call Duration Limitation:	0
Enable Call Duration Limitation:	<input type="checkbox"/> OFF

Call Duration Limitation: This will limit your total calling time of this port. If remain time is 0, it will not send calls through this port.

Figure 3-7-4 Call Duration Limitation Settings

Call Limit Time	
Call Time Limit Switch:	<input checked="" type="checkbox"/> ON
Step:	60
Second	
Enable Single Call Duration Limit:	<input checked="" type="checkbox"/> ON
Single Call Duration Limitation:	0
Enable Call Duration Limitation:	<input checked="" type="checkbox"/> ON
Call Duration Limitation:	10
Minimum Charging Time:	30
Second	
Alarm Threshold:	2
Alarm Phone Number:	18610001000
Alarm Description:	test
Remain Time:	0
<input type="button" value="Reset"/>	
Enable Auto Reset:	<input checked="" type="checkbox"/> ON
Auto Reset Type:	Week(7Day) ▼
Next Reset Time:	2019-04-01 16:29:35

The same as the algorithm for the single call duration limit, the total call time of the port cannot exceed the product of the “Step” and the “Call Duration Limitation”. The Minimum Billing Time value must be less than the step size.

You can set a value for the Alarm Threshold. When the remaining call duration of the port reaches the set value, the gateway will send alarm info to the designated phone.

You can also turn on enable auto reset, which can be selected from one day, one week or one month. After the automatic reset time is reached, the remaining call duration is reset to the set total call duration.

Figure 3-7-5 Auto Reset Settings

Enable Auto Reset:	ON
Auto Reset Type:	Week(7Day)
Next Reset Time:	2019-04-01 16:29:35

Table 3-7-1 Description of Call Duration Limit Settings

Options	Definition
Step	The value range of the step length is 1-999s. Multiplying the step size by a single call time is to allow a single call duration.
Enable Single Call Duration Limit	The value of the single call duration limit, ranging from 1-999999. The step size multiplied by the single talk time is the single call duration.
Enable Call Duration Limitation	The value of the total call duration limit, in the range of 1-999999. The step size multiplied by the total talk time is the total call duration.
Minimum Charging Time	After a period of conversation, the operator starts billing, in seconds. This value must be less than the step size.
Alarm Threshold	The threshold for the duration of the call. When the duration of the call is equal or less than this value, the gateway will send an alert message to the specified phone number via SMS (only once before the total call duration is reset). This value must be less than the call duration limit.

Alarm Phone Number	User will received alarm message from the gateway when receiving alarm phone number.
Alarm Description	The alarm port information description sends the alarm information to the user's phone.
Remaining call duration	Multiplying this value by the step size is the remaining call duration.
Enable Auto Reset	The remaining talk time is automatically restored, that is, the total number of minutes of the call is restored.
Auto Reset Type	Reset call minutes by date, by week, by month.
Next Reset Time	Define the next reset date. The system will count from that date and be set as a reset period.

Lock Card

The lock card detection switch is a switch function of the lock card. After opening, the call failure lock card condition parameter needs to be set. After the lock card condition is reached, the SIM card is disabled and cannot be allocated for use unless the card is removed, the gateway is restarted, and the manual is unlocked (Duration limit requires manual reset), turn off the lock card function, etc.

Figure 3-9-6 Lock Card

Lock Sim	
Lock Detect Switch:	<input checked="" type="checkbox"/>
Mark Switch:	<input checked="" type="checkbox"/>
Call Failed Mark Count:	3
Call Failed Lock Switch:	<input checked="" type="checkbox"/>
Call Failed Lock Count:	3
SMS Send Detection Switch:	<input checked="" type="checkbox"/>
SMS Send Detection Count:	10
Send Sms Number:	13810001000
Sms Message:	test s
Testing SMS report:	<input checked="" type="checkbox"/>

Table 3-7-3 Description of Lock Card

Options	Definition
Call Failed Mark Count	The number of consecutive calls failed to reach the number of settings, making the port.
Called Failed Lock Count	Lock the port after the number of successive call failures reaches the set number, restrict the port expiration, and no longer select the port expiration in the group policy.
SMS Send Detection Switch	After opening, when the number of successive call failures reaches the set value, send message to check whether the port is available; if the message send successfully, it will clear the number of successive call failures; if the message fails, it will limit the port's outgoing.
Testing SMS report	When closed, the successful sending of message indicates that the port is available; when opened, the successful sending of message and the receipt of message report indicate that the port is available.

SMS Limit

Figure 3-7-7 SMS Limit

SMS Limit	
SMS Limit Switch	ON <input checked="" type="checkbox"/>
SMS Limit Success Flag	ON <input checked="" type="checkbox"/>
Day Limit SMS Count	0 <input type="text"/>
Month Limit SMS Count	5 <input type="text"/>
SMS Clean Date	1 <input type="button" value="▼"/>

Table 3-7-4 Definition of SMS Limit

Options	Definition
SMS Limit Success Flag	When closed, no matter whether the message is sent successfully or not, the number of messages is counted ; When opened, the number of messages is counted when the message is sent successfully.
Day Limit SMS Count	Limit the number of SMS sent daily, the default value is 0, indicating unlimited.
Month Limit SMS Count	Limit the number of SMS sent per month, the default value is 0, indicating unlimited.
SMS Clean Date	The number of messages sent monthly is automatically cleared at 0 points, 0 minutes and 0 seconds on the set date.

3.8 the strategy of switching card

This page displays the status information of each card slot. You can see the corresponding status of each card slot.

Figure 3-8-1 the status of card slots

Port	Card 1	Card 2	Card 3	Card 4	Actions
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					

Open the switch of switching card strategy and set the switching card policy.

According to the set sim card registration time, use time, call out time, call out times and SMS send times, the card can be switched in ascending or descending order.

Figure 3-8-2 the setting of switching card strategy

strategy (cdma-5)

Switch:	<input checked="" type="checkbox"/> ON	
Sim Policy:	Asc ▾	
Registration Time:	120	Second
Using Time:	5	Minute
Callout Time:	0	Minute
Callout Count:	0	
SMS Count:	0	

Save To Other Ports

Save To Other Ports:	<input type="checkbox"/> cdma-1 <input checked="" type="checkbox"/> cdma-5 <input type="checkbox"/> cdma-9 <input type="checkbox"/> cdma-13 <input type="checkbox"/> lte-17 <input type="checkbox"/> gsm-21 <input type="checkbox"/> All	<input type="checkbox"/> cdma-2 <input type="checkbox"/> cdma-6 <input type="checkbox"/> cdma-10 <input type="checkbox"/> cdma-14 <input type="checkbox"/> lte-18 <input type="checkbox"/> gsm-22	<input type="checkbox"/> cdma-3 <input type="checkbox"/> cdma-7 <input type="checkbox"/> cdma-11 <input type="checkbox"/> cdma-15 <input type="checkbox"/> lte-23	<input type="checkbox"/> cdma-4 <input type="checkbox"/> cdma-8 <input type="checkbox"/> cdma-12 <input type="checkbox"/> cdma-16 <input type="checkbox"/> gsm-19 <input type="checkbox"/> gsm-20 <input type="checkbox"/> lte-24
----------------------	--	--	---	---

Sync All Settings: Select all settings

4. VOIP

4.1 VOIP Endpoints

This page shows everything about your SIP&IAX2, you can see the status of each SIP&IAX2.

Figure 4-1 SIP&IAX2 Endpoints

SIP Endpoint			
Endpoint Name	Registration	Credentials	Actions
10028	none	anonymous@172.16.208.33	
2111	server	test	
Add New SIP Endpoint Delete			

IAX2 Endpoint			
Endpoint Name	Registration	Credentials	Actions
2133	client	2133@172.16.208.33	
Add New IAX2 Endpoint Delete			

4.1.1 Add New SIP Endpoint

Main SIP Endpoint Settings:

You can click button to add a new SIP endpoint, and if you

want to modify existed endpoints, you can click button.

There are 3 kinds of registration types for you to choose: None, Server or Client. You can configure as follows:

If you set up a SIP endpoint by registration “None” to a server, then you can’t register other SIP endpoints to this server (If you add other SIP endpoints, this will cause Out-band Routes and Trunks confused).

Figure 4-1-1 None Registration

This screenshot shows the 'Main Endpoint Settings' configuration page. The 'Registration:' dropdown menu is highlighted with a red box and contains the option 'None'. Other fields visible include 'Name: 6666', 'User Name:', 'Password:', 'Hostname or IP Address: 172.16.200.20', 'Transport: UDP', and 'NAT Traversal: Yes'.

For convenience, we have designed a method that you can register your SIP endpoint to your gateway, thus your gateway just work as a server.

Figure 4-1-2 Server Registration

This screenshot shows the 'Main Endpoint Settings' configuration page. The 'Registration:' dropdown menu is highlighted with a red box and contains the option 'Server'. Other fields visible include 'Name: 10027', 'User Name: 10027', 'Password:', 'Hostname or IP Address: dynamic', 'Transport: UDP', and 'NAT Traversal: Yes'.

Also you can choose registration by "This gateway registers with the endpoint", it's the same with "None", except the name and the password.

Figure 4-1-3 Client Registration

This screenshot shows the 'Main Endpoint Settings' configuration page. The 'Registration:' dropdown menu is highlighted with a red box and contains the option 'Client'. Other fields visible include 'Name: 10027', 'User Name: 10027', 'Password:', 'Hostname or IP Address: 172.16.80.16', 'Transport: UDP', and 'NAT Traversal: Yes'.

Table 4-1-1 Definition of SIP Options

Options	Definition
Name	A name is easier to understand, only for reference, does not participate in SIP authentication.

Username	Register name in your SIP server.
Password	Authenticating with the gateway and characters are allowed.
Registration	<p>Whether the terminal registers with the gateway or the gateway registers with the terminal.</p> <p>None --- Not registering;</p> <p>Server --- When register as this type, it means the gateway acts as a SIP server, and SIP endpoints register to the gateway;</p> <p>Client --- When register as this type, it means the gateway acts as a client, and the endpoint should be register to a SIP server;</p>
Hostname or IP Address	<p>IP address or hostname of the endpoint or 'dynamic' if the endpoint has a dynamic IP address. This will require registration.</p> <p>Notice: If you entered the domain name and changed the DNS, you must restart asterisk.</p>
Transport	<p>This sets the possible transport types for outgoing. Order of usage, when the respective transport protocols are enabled, is UDP, TCP, TLS.</p> <p>The first enabled transport type is only used for outbound messages until a Registration takes place. During the peer registration the transport type may change to another supported type if the peer requests so.</p>
NAT Traversal	<p>No --- Use report if the remote needs it.</p> <p>Force Report on—Force report on.</p> <p>Yes --- Force the report to open and perform commedia RTP processing.</p> <p>Report if requested and commedia --- If the remote needs it,</p>

	use report and perform commedia RTP processing.
--	---

Advanced: Registration Options

Figure 4-1-4 Advanced Registration Options

The screenshot displays the 'Advanced:Registration' configuration interface. It includes fields for Authentication User (108), Register Extension (108), Register User (108), Contact User, From User, From Domain, Port (5060), Qualify (No), Qualify Frequency (60), Outbound Proxy, Custom Registry (OFF), and Enable Outboundproxy to Host (OFF). Each field has a 'Modify' checkbox next to it.

Table 4-1-2 Definition of Registration Options

Options	Definition
Authentication User	Just a username used when registering.
Register Extension	When Gateway registers as a SIP user agent to a SIP proxy (provider), calls from this provider connect to this local extension.
Register User	Register user name, it is the user of register => user[:secret[:authuser]]@host[:port][/extension].
Contact User	e.g. When the Contact User is 402

	Contact: sip:402@172.16.6.123:5060;transport=UDP.
From User	A username to identify the gateway to this endpoint.
From Domain	A domain to identify the gateway to this endpoint.
Port	The port number used by the gateway to link the peer.
Qualify	Whether to check the link status of the peer.
Qualify Frequency	How often, in seconds, to check the endpoint's connection status.
Outbound Proxy	A proxy to which the gateway will send all outbound signaling instead of sending signaling directly to endpoints.
Custom Registry	After opening, customers can customize their own registry.
Registry String	Customers can enter their own registration information. The format is:: user[:secret[:authuser]]@host[:port][/:extension] e.g.: 1001@sip.com:pbx122@172.16.6.122/1001.
Enable Outbound proxy to Host	Outbound proxy to Host On / Off.

Call Settings

Figure 4-1-5 Call Settings

The screenshot shows the 'Call Settings' configuration page. It includes the following sections:

- DTMF Settings:** DTMF Mode: RFC2833
- Caller ID Settings:**
 - Trust Remote-Party-ID: No
 - Send Remote-Party-ID: No
 - Caller ID Presentation: Allowed.passed screen
- Maximum Channels:** Call Limit: [empty input field]

Table 4-1-3 Description of DTMF Detection Settings

Options	Definition
DTMF Mode	Set default DTMF Mode for sending DTMF. Default: rfc2833. Other options: 'info', SIP INFO message (application/dtmf-relay); 'Inband', Inband audio(require 64kbit codec -alaw,ulaw).
Trust Remote-Party-ID	Whether or not the Remote-Party-ID header should be trusted.
Send Remote-Party-ID	Whether or not to send the Remote-Party-ID header.
Remote-Party-ID Format	How to set the Remote-Party-ID header: from Remote-Party-ID or from P-Asserted-Identity.
Caller ID Presentation	Whether or not to display the Caller ID.

Call Limit	Usually used when this sip works as a trunk. Limit the maximum number of channels supported by sip trunks.
------------	--

Advanced: Signaling Settings

Figure 4-1-6 Signaling Settings




Table 4-1-4 Definition of Signaling Options

Options	Definition
Progress Inband	Whether the tone is ringing. Never: Indicates that the incoming calls are never applied. Option values: yes, no, never. Default: never.
Append user=phone to URI	Whether or not to add ‘user=phone’ to URIs that contain a valid phone number.
Add Q.850 Reason Headers	Whether or not to add a reason header and use it if is available.
Ignore SDP Version	By default, the gateway will honor the session version number in SDP packets and will only modify the SDP session if the version number changes.

	Switch this option off to force the gateway to ignore the SDP session version number and treat all SDP data as new data. This is required for devices that send non-standard SDP packets (observed with Microsoft OCS). By default this option is on.
Direct media	The value of parameter direct media is one of them (no, yes, nonat, update, outgoing). Default value is yes.
Allow Transfers	Whether or not to globally enable transfers. Choosing 'no' will disable all transfers (unless enabled in peers or users). Default is enabled.
Allow Promiscuous Redirects	Whether or not to allow 302 or REDIR to non-local SIP address. Notice: Redirecting the local system causes a loop call, which is not supported by asterisk.
Max Forwards	Setting for the SIP Max-Forwards header (loop prevention).
Send TRYING on REGISTER	Send a 100 Trying when the endpoint registers.

Advanced: Timer Settings

Figure 4-1-7 Timer Settings

Advanced:Timer Settings

Default T1 Timer:	500
Call Setup Timer:	32000
Session Timers:	Accept ▾
Minimum Session Refresh Interval:	90
Maximum Session Refresh Interval:	1800
Session Refresher:	UAS ▾

Table 4-1-5 Definition of Timer Options

Options	Definition
Default T1 Timer	This timer is used primarily in INVITE transactions. The default for Timer T1 is 500 ms or the measured run-trip time between the gateway and the device if you have qualify=yes for the device.
Call Setup Timer	If a provisional response is not received in this amount of time, the call will auto congest. The default is 64*T1.
Session Timers	There are three modes for you to choose: originate, request and run session-timers always; Accept or run the session timer only when requested by another user agent; Refuse, Do not run session timers in any case.
Minimum Session Refresh Interval	Minimum session refresh interval in seconds. The default is 90 secs.
Maximum Session Refresh Interval	Maximum session refresh interval in seconds. The default is 1800secs.
Session Refresher	The session refresher, UAC or UAS. The default is UAS.

4.1.2 Add New IAX2 Endpoint

You can click **Add New IAX2 Endpoint** button to add a new IAX2 endpoint and if you



want to modify existed endpoints, you can click **Edit** button.

There are three registration types: None, Server or Client.

You can configure as follows:

If you set up an IAx2 endpoint by registration “None” to a server, then you can’t register other IAX2 endpoints to this server, just authenticate the username and password.

Figure 4-1-8 None Registration

The screenshot shows the 'Main Endpoint Settings' configuration page. The 'Registration:' dropdown menu is highlighted with a red box and contains the option 'None'. Other fields visible include 'Name: iax-test', 'User Name: 1001', 'Password:', 'Hostname or IP Address: 172.16.80.92', 'Auth: md5', 'Transfer: No', and 'Trunk: No'.

For convenience, you can choose registration by “Server”, thus your gateway just work as a server.

Figure 4-1-9 Server Registration

The screenshot shows the 'Main Endpoint Settings' configuration page. The 'Registration:' dropdown menu is highlighted with a red box and contains the option 'Server'. Other fields visible include 'Name: iax-test', 'User Name: 1001', 'Password:', 'Hostname or IP Address: dynamic', 'Auth: md5', 'Transfer: No', and 'Trunk: No'.

Also you can choose registration by "Client", it will work as a Client.

Figure 4-1-10 Client Registration

The screenshot shows a configuration interface for a main endpoint. The 'Registration' field is highlighted with a red box and contains the value 'Client'. Other fields include Name (iax-test), User Name (1001), Password (*****), Hostname or IP Address (172.16.80.92), Auth (md5), Transfer (No), and Trunk (No).

Table 4-1-6 Definition of IAX2 Options

Options	Definition
Name	A name which is able to read by human. And it's only used for user's reference.
Username	The endpoint will use username to authenticate with the gateway.
Password	The endpoint will use password to authenticate with the gateway.
Registration	<p>Whether this endpoint will register to this gateway or this gateway to the endpoint.</p> <p>None --- Not registering;</p> <p>Endpoint registers with this gateway --- When register as this type, it means the gateway acts as a IAX2 server, and IAX2 endpoints register to the gateway;</p> <p>This gateway registers with the endpoint --- When register as this type, it means the gateway acts as a IAX2 client, and the endpoint should be register to a IAX2 server;</p>
Hostname or	IP address or hostname of the endpoint or 'dynamic' if the

IP Address	endpoint has a dynamic IP address. This will require registration. Notice: If you entered the domain name and changed the DNS, you must restart asterisk.
Auth	There are three authentication methods that are supported: md5, plaintext and rsa. The least secure is "plaintext", which sends passwords clear text across the net. Uses a challenge/response md5 sum arrangement, but still requires both ends have plain text access to the secret. "rsa" allows unidirectional secret knowledge through public/private keys.
Transfer	Disable or not IAX2 native transfer.
Trunk	Use IAX2 trunking with this host.

Advanced: Registration Options

Figure 4-1-11 Registration Options

Qualify:	Yes
Qualify Smoothing:	Yes
Qualify Freq Ok:	6000
Qualify Freq Not Ok:	6000
Port:	4569
Require Call Token:	Yes

Table 4-1-7 Definition of Registration Options

Options	Definition
Qualify	Whether or not to check the endpoint's connection status.
Qualify Smoothing	Use the average of the last two connection results to

	reduce the lag end of the misdetection. The default is no.
Qualify Freq Ok	How frequently to ping the peer when everything seems to be OK, in milliseconds
Qualify Freq Not Ok	How frequently to ping the peer when it is either, LAGGED or UNAVAILABLE, in milliseconds.
port	The port number the gateway will connect to at this endpoint. Default is 4569.

IAX2 Encryption

Figure 4-1-12 IAX2 Encryptions



Table 4-8 Definition of Encryption Options

Options	Definition
Encryption	Enable IAX2 encryption. The default is no.
Force Encryption	Force encryption insures no connection is established unless both sides support encryption. By switching this option on, encryption is automatically switch on as well. The default is

	no.
--	-----

IAX2 Trunk Settings

Figure 4-1-13 IAX2 Trunk Settings

IAX2 Trunk settings	
Trunk Max Size:	128000
Trunk MTU:	0
Trunk Frequency:	20
Trunk Time Stamps:	No
Min. RegExpire:	60
Max. RegExpire:	60

Table 4-1-9 Definition of Trunk Options

Options	Definition
Trunk Max Size	The default is 128000 bytes, which supports up to 800 calls of ulaw at 20ms a frame.
Trunk MTU	Set the maximum transmission unit for IAX2 UDP trunking.
Trunk Frequency	How frequently to send trunk messages in msec. This is 20ms by default.
Trunk Time Stamps	Ensure that frame timestamps get sent end-to-end properly.
Min. RegExpire	Minimum amounts of time that IAX2 peers can request as a registration expiration interval in seconds.
Max. RegExpire	Maximum amounts of time that IAX2 peers can request as a registration expiration interval in seconds.

4.2 Batch SIP Endpoints

On this page, you can create multiple SIP Endpoints at the same time.

Figure 4-2-1 Multiple SIP Endpoints Settings

ID	User Name	Password	Hostname or IP Address	Port	Register Mode
1					client ▾
2					client ▾
3					client ▾
4					client ▾
5					client ▾
6					client ▾
7					client ▾
8					client ▾

You should select the number of SIPS to be created after you filling in the username, password, domain name or IP address, port and registration mode in the first line.

You can create up to the same number of SIP endpoints as the number of device ports at a time; Then choose whether to tick “AutoPassword” button. After the above configuration is completed, click Batch Settings, and then save to create SIP endpoints in batches.

Table 4-2-1 Definition of Multiple SIP Endpoints

Options	Definition
Username	The display name is the same as the registered name on the SIP server by default.
Password	Authenticating with the gateway and characters are allowed.
Hostname or IP Address	IP address or hostname of the endpoint or 'dynamic' if the endpoint has a dynamic IP address. This will require registration.
Port	Port number registration

Registration	<p>None --- Not registering;</p> <p>Server --- When register as this type, it means the gateway acts as a SIP server, and SIP endpoints register to the gateway;</p> <p>Client --- When register as this type, it means the gateway acts as a client, and the endpoint should be register to a SIP server;</p>
AutoPassword	<p>Tick - Automatically increments based on the password entered in the first line.</p> <p>Do not tick- All SIP endpoints have the same password as the first one.</p>

4.3 Advanced SIP Settings

Networking

Figure 4-3-1 Networking General

General	
UDP Bind Port:	5060
Enable TCP:	No
TCP Bind Port:	5060
TCP Authentication Timeout:	
TCP Authentication Limit:	
Enable Hostname Lookup:	No
Enable Internal SIP Call:	No
Internal SIP Call Prefix:	

Table 4-3-1 Definition of Networking General Options

Options	Definition

UDP Bind Port	Choose a port on which to listen for UDP traffic.
Enable TCP	Enable server for incoming TCP connection (default is no).
TCP Bind Port	Choose a port on which to listen for TCP traffic.
TCP Authentication Timeout	The maximum number of seconds a client has to authenticate. If the client does not authenticate before this timeout expires, the client will be disconnected (default value is: 30 seconds).
TCP Authentication Limit	The maximum number of unauthenticated sessions that will be allowed to connect at any given time (default is: 50).
Enable Hostname Lookup	Enable DNS SRV lookups on outbound calls. Notice: The gateway uses the first host in the SRV record. This function can be used in dial-up activation to dial SIP calls on the Internet via domain name.
Enable Internal SIP Call	Whether enable the internal SIP calls or not when you select the registration option "Endpoint registers with this gateway".
Internal SIP Call Prefix S	Specify a prefix before routing the internal calls.

Figure 4-3-2 NAT Settings

NAT Settings	
Local Network:	<input type="text"/> <input type="button" value="Add"/>
Local Network List:	<input type="text"/> <input type="button" value="IP Range"/> <input type="button" value="Action"/>
Subscribe Network Change Event:	No <input type="button"/>
Match External Address Locally:	No <input type="button"/>
Dynamic Exclude Static:	No <input type="button"/>
Externally Mapped TCP Port:	<input type="text"/>
External Address:	<input type="text"/> <input type="button"/> Auto Update <input type="button" value="Get IP"/>
External Hostname:	<input type="text"/>
Hostname Refresh Interval:	<input type="text"/>

Table 4-3-2 Definition of NAT Settings Options

Options	Definition
Local Network	Format:192.168.0.0/255.255.0.0 or 172.16.0.0./12. A list of IP address or IP ranges which are located inside a NAT network. This gateway will replace the internal IP address in SIP and SDP messages with the external IP address when a NAT exists between the gateway and other endpoints.
Local Network List	Add local IP address list.
Subscribe Network Change Event	Through the use of the test_stun_monitor module, the gateway has the ability to detect when the perceived external network address has changed. When the stun_monitor is installed and configured, chan_sip will renew all outbound registrations when the monitor detects any sort of network change has occurred. By default this option is enabled, but res_stun_monitor only takes effect once. If res_stun_monitor is enabled and you don't want changes on the network to cause an outbound registration, use the option below to disable this feature.
Match External Address Locally	Only substitute the extern address or extern host setting if it matches.

Dynamic Static	Exclude	Dynamic hosts are not allowed to register with the static host's IP address, which will avoid the same IP registration error.
Externally TCP Port	Mapped	The externally mapped TCP port, when the gateway is behind a static NAT or PAT.
External Address		<p>The external address (and optional TCP port) of the NAT. External Address = hostname[:port].</p> <p>Specifies a static address[:port] to be used in SIP and SDP messages. Examples:</p> <p>External Address = 12.34.56.78</p> <p>External Address = 12.34.56.78:9900.</p>
Hostname Interval	Refresh	How often to perform a hostname lookup. This can be useful when your NAT device lets you choose the port mapping, but the IP address is dynamic. Beware, you might suffer from service disruption when the name server resolution fails.

Figure 4-3-3 RTP Settings

RTP Settings	
Start of RTP Port Range:	<input type="text" value="10000"/>
End of RTP port Range:	<input type="text" value="20000"/>
RTP Timeout:	<input type="text" value="120"/>

Table 4-3-3 Definition of RTP Settings Options

Options	Definition
Start of RTP Port Range	Start of port numbers to be used for RTP.

End of RTP port Range	End of port numbers to be used for RTP.
-----------------------	---

Parsing and compatibility

Figure 4-3-4 Parsing and Compatibility

Table 4-3-4 Instruction of Parsing and Compatibility

Options	Definition
Strict RFC Interpretation	Check header tags, character conversion in URIs, and

	multiline headers for strict SIP compatibility (default is yes).
Send Compact Headers	Send compact SIP headers.
SDP Owner	Allows you to change the username filed in the SDP owner string. This field MUST NOT contain spaces
Disallowed SIP Methods	When a dialog is started with another SIP endpoint, the other endpoint should include an Allow header telling us what SIP methods the endpoint implements. However, some endpoints either do not include an Allow header or lie about what methods they implement. In the former case, the gateway makes the assumption that the endpoint supports all known SIP methods. If you know that your SIP endpoint does not provide support for a specific method, then you may provide a list of methods that your endpoint does not implement in the disallowed methods option. Note that if your endpoint is truthful with its Allow header, then there is no need to set this option.
Shrink Caller ID	The Shrink Caller Id function removes '(', ')', ' ', non-trailing '.', and '-' not in square brackets. For example, the caller id value 555.5555 becomes 5555555 when this option is enabled. By default, this option is on.
Caller ID	Default: SIP From and Number. For example: When selecting SIP From, Name is

	Peter and Number is 402. The From mode is: "Peter"<sip:402@172.16.6.239;transport=UDP>;tag=bd481672.
Callee ID	Default: EXTE For example: When selecting SIP To, Name is Jason and Number is 401. The mode is: "Jason"<sip:401@172.16.6.239;transport=UDP>.
Maximum Registration Expiry	Maximum allowed time of incoming registrations and subscriptions (seconds).
Minimum Registration Expiry	Minimum length of registrations/subscriptions (default 60).
Default Registration Expiry	Default length of incoming/outgoing registration.
Registration Timeout	How often, in seconds, to retry registration calls. Default 20 seconds.
Number of Registration	Number of registration attempts before we give up.

Security

Figure 4-3-5 Security Settings

The screenshot shows the 'Security' configuration page. It includes the following settings:

- Authentication Settings:**
 - Match Auth Username: No
 - Realm: (empty input field)
 - Use Domain as Realm: No
 - Always Auth Reject: No
 - Authenticate Options Requests: No
- Guest Calling:**
 - Allow Guest Calling: No

Table 4-3-5 Instruction of Security

Options	Definition
Match Auth Username	If available, match user entry using the 'username' field from the authentication line instead of the 'from' field.
Realm	Realm for digest authentication. All realms must be globally unique according to the RFC3261 standard and can generally be set to hostname or domain name.
Use Domain as Realm	Use the domain from the SIP Domains setting as the realm.
Always Auth Reject	When an INVITE or REGISTER request is rejected for any reason, the same reason is always used, the username is legal but the password is incorrect. It does not tell the requester whether there is this user or peer, which will reduce the possibility of the attacker scanning the SIP account. This parameter is enabled by default.
Authenticate Options Requests	Enabling this option will authenticate OPTIONS requests just like INVITE requests are. By default this option is disabled.
Allow Guest Calling	Allow or reject customer calls (default yes, allowed). If your gateway is connected to the Internet and allows customers to call, you want to check which services are available to everyone, by enabling them in the default context.

Media

Figure 4-3-6 Media Settings**Table 4-3-6 Instruction of Media**

Options	Definition
TOS for SIP Packets	Sets type of service for SIP packets.
TOS for RTP Packets	Sets type of service for RTP packets.

Codec Settings

Select codecs from the list below.

Figure 4-3-7 Codec Settings

4.4 Advanced IAX2 Settings

General Settings

Figure 4-4-1 General Settings

General Settings	
Bind Port:	4569
Bind Address:	0.0.0.0
Enable IAXCompat:	No
Enable Nochecksums:	No
Enable Delay Reject:	No
ADS:	No
SRV Loopup:	No
AMA Flags:	default
Auto Kill:	Yes
Language:	English
Account Code:	
Call Token Optional:	
Description:	

Table 4-4-1 Instruction of General

Options	Definition
Bind Port	Bind port and bindaddr may be specified.
Enable IAXCompat	Set laxcompat to yes if you need to use a tiered switch, or if some of the latency may occur when performing a lookup in a dial plan, otherwise enabling it will result in a small performance conflict.
Enable Nochecksums	Disable UDP checksums (if Nochecksums is set, then Nochecksums will be calculated/checked on systems supporting this feature).
ADS	ADS (Analog Display Services Interface) can be enabled if you have (or may have) ADSI compatible CPE equipment.
SRV Lookup	Whether or not to perform an SRV lookup on outbound calls.
AMA Flags	You may specify a global default AMA flag for IAX internal calls. These flags are used in the generation of call detail records.

Auto Kill	If we don't get ACK to our NEW within 2000ms, and Auto Kill is set to yes ,then we cancel the whole thing (that's enough time for one retransmission only). This is used to keep things from stalling for a long time for a host that is not available, However, this function is not friendly in the case of poor connection status.
Language	You may specify a global default language for users. This can be specified also on a per-user basis. If you ignore this item, it will use the default English language.
Account Code	You may specify a default account for Call Detail Records (CDRs) in addition to specifying on a per-user basis.

Music on Hold

Figure 4-4-2 Music on Hold Settings



Table 4-4-2 Instruction of Music on Hold

Options	Definition
Mohsuggest	Specifies the type of waiting music that plays while the channel is on hold. It can specify global settings or be specified by the user or each peer.
Mohinterpret	Set the content of the channel playback when the phone is suspended. If it is "default", the music specified in the dialing

	rules will be played in the channel when the phone hangs. If it is "transfer", it will be replaced by a message signal.
--	---

Instruction of Codec Settings

Figure 4-4-3 Codec Settings




Table 4-4-3 Instruction of Codec Settings

Options	Definition
Band Width	Specify bandwidth of low, medium, or high to control which codes are used in general.
Disallow	Adjust the type of codec to be switched off.
Allow	Adjust the type of codec to be switched on and the priority.
Codec Priority	Codec priority controls the codec negotiation of an inbound IAX2 call. This option is inherited to all user entities. It can also be defined in each user entity separately which will override the setting in general.

Jitter Buffer Settings

Figure 4-4-4 Jitter Buffer

Jitter Buffer Settings	
Jitter Buffer:	No ▾
Force Jitter Buffer:	No ▾
Max Jitter Buffers:	
Resyncthreshold:	
Max Jitter Interps:	
Jitter Target Extra:	

Table 4-4-4 Instruction of Jitter Buffer

Options	Definition
Jitter Buffer	Whether to set a global buffer should be enabled by an unstable network environment, generally you do not need. Because the terminal device buffers the jitter processing. The default is "no".
Force Jitter Buffer	In the ideal world, when we bridge VoIP channels we don't want to jitter buffering on the switch, since the endpoints can each handle this. However, some endpoints may have poor jitter buffers themselves, so this option will force to always jitter buffer, even in this case. The default is "no".
Max Jitter Buffers	A maximum size for the jitter buffer.
Resyncthreshold	When the jitter buffer notices a significant change in delay that continues over a few frames, it will resync, assuming that the change in delay was caused by a timestamping mix-up. The threshold for noticing a change in delay is measured as twice the measured jitter plus this resync threshold. Resyncing can be disabled by setting this

	parameter to -1.
Max Jitter Interps	The maximum number of interpolation frames the jitter buffer should return in a row.
Jitter Target Extra	Number of milliseconds by which the new jitter buffer will pad its size. The default is 40, so without modification, the new jitter buffer will set its size to the jitter value plus 40 milliseconds. Increasing this value may help if your network normally has low jitter, but occasionally has spikes.

Misc Settings

Figure 4-4-5 Misc Settings

▼ Misc Settings	
IAX2 Thread Count:	<input type="text"/>
IAX2 Max Thread Count:	<input type="text"/>
Max Call Number:	<input type="text"/>
MaxCallNumbers_Nonvalidated:	<input type="text"/>

Table 4-4-5 Instruction of Misc Settings

Options	Definition
IAX Thread Count	Establishes the number of IAX helper threads to handle I/O
IAX2 Max Thread Count	Establishes the number of extra dynamic threads that may be spawned to handle I/O.

Max Call Number	The 'Max Call Numbers' option limits the amount of call numbers allowed for each individual remote IP address. Once an IP address reaches its call number limit, no more new connections are allowed until the previous ones close. This option can be used in a peer definition as well, but only takes effect for the IP of a dynamic peer after it completes registration.
MaxCallNumbers_Nonvalidated	The 'MaxCallNumbers_Nonvalidated' is used to set the combined number of call numbers that can be allocated for connections where call token validation has been disabled. Unlike the ' Max Call Number ' option, this limit is not separate for each individual IP address. Any connection resulting in a non-call token validated call number being allocated contributes to this limit. For use cases, see the call token user guide. This option's default value of 8192 should be sufficient in most cases.

Quality of Service

Figure 4-4-6 Quality of Service




Table 4-4-6 Instruction of Quality of Service

Options	Definition
TOS	Type of service.
COS	Class of service.

4.5 SIP Account Security

The SIP account security module greatly enhances the security of the system. The wireless gateway supports TLS encrypted calls (sip), which requires sip phone support.

Figure 4-5-1 SIP Account Security



You need to understand its rules when using TLS. The following table shows the setting parameters of TLS.

Table 4-5-1 Parameters of TLS settings

Options	Definition
TLS Enable	Enable or disable DTLS-SRTP support.
TLS Verify Server	If set it off, there is no need to verify the server certificate when the client is operating. If you do not have a server CA certificate, you can disable authentication to connect without the need for a TLS CA file.
Port	TLS port SIP registration, default port 5061.

TLS Client Method	Values include tlsv1, sslv3, sslv2, which specify the protocol for the outbound client connection. The default is sslv2.
-------------------	--

Enter the key name, IP address, organization and password in the above settings to create a ca certificate. After mutual authentication between the client and the server, it can be accessed with a certificate.

We need to do a few basic steps:

1. Your asterisk server requires an authentication. We must create or add a certificate on the asterisk server. We need to create a digital key for our server, the server key is the key.pem file, and the certificate request is request.pem.
2. Add some configuration settings to the sip.conf file.
3. Configure the client to use TLS.

5. Routing

5.1 Call Routing Rules

Figure 5-1-1 Call Routing Rules

	Move	Order	Rule Name	From	To	Rules	Actions
		1	incoming	grp-all	iax-2133		
		2	outgoing	sip-2111	lte-1.2		
		3	test	sip-10028	gsm-2.6	Dial_pattern ()>1[.]	
New Call Routing Rule Delete Save Orders							

You are allowed to set up new call routing rules by [New Call Routing Rule](#), and after

setting routing rules, move rules' order by pulling up and down, click button to edit the routing and to delete it. Finally click the button [Save Orders](#) to save what you set.

Call Routing Rules

You can click [New Call Routing Rule](#) button to set up your routings.

Figure 5-1-2 Call Routing Rules

Call Routing Rule

Routing Name:	incoming
Call Comes in From:	all <small>None</small> <small>Any SIP</small> <small>Port</small> <ul style="list-style-type: none"> lte-1.1 lte-1.2 lte-1.3 lte-1.4
Send Call Through:	<small>DISA Settings</small> <small>Authentication:</small>
<small>Advance Routing Rule</small>	
<input type="button" value="Save"/> <input type="button" value="Apply"/> <input type="button" value="Cancel"/>	

The figure above shows that all the phones in the group ALL are transferred to the IAX2-2133. When the "incoming source" is GSM/LTE port, "prepend", "prefix" and "match pattern" in the "Advanced Routing Rules" are invalid, and only the "CallerID" option is available.

Table 5-1-1 Definition of Routing Options

Options	Definition
Routing Name	The name of this route. Should be used to describe what types of calls this route matches (for example: 'sip1TOport1' or 'port1TOsip1').
Call Comes in From	The launching point of incoming calls.
Send Call Through	The destination to receive the incoming calls.

Figure 5-1-3 DISA Settings

In the DISA Settings, you can set a Password, Authentication or Secondary Dialing.

Figure 5-1-4 Advance Routing Rule Settings

The screenshot displays the 'Advance Routing Rule' configuration page. It includes fields for defining dial patterns, specifying time groups, setting change rules (Caller ID, Forward Number, Custom Context), and managing failover call-through providers.

- Dial Patterns that will use this Route:** Fields for (prepend) + prefix, match pattern, and Callerid.
- Time Patterns that will use this Route:** Fields for Time to start, Time to finish, Week Day start, Week Day finish, Month Day start, Month Day finish, Month start, Month finish.
- Change Rules:** Set the Caller ID Name to, Set the Caller ID Number to, Forward Number, Custom Context, Random Delay (OFF).
- Failover Call Through Number:** Add a Failover Call Through Provider.

In the Advance Routing Rule Settings, you can set the function of the dial Patterns、Time Patterns、Calling, Forward, Delay and Failover.

Table 5-1-2 Description of Advanced Routing Rule

Options	Definition
Dial Patterns that will use this Route	<p>A Dial Pattern is a unique set of digits that will select this route and send the call to the designated trunks. If a dialed pattern matches this route, no subsequent routes will be tried. If Time Groups are enabled, subsequent routes will be checked for matches outside of the designated time(s).</p> <p>Rules:</p> <ul style="list-style-type: none">X matches any digit from 0-9Z matches any digit from 1-9N matches any digit from 2-9[1237-9] matches any digit in the brackets (for example: 1,2,3,7,8,9).Wildcard: matches one or more dialed digits.Prepend: Digits to prepend to a successful match.

	<p>If the dialed number matches the patterns specified by the subsequent columns, then this will be prepended before sending to the trunks.</p> <p>Prefix: Prefix to remove on a successful match.</p> <p>The dialed number is compared to this and the subsequent columns for a match. Upon a match, this prefix is removed from the dialed number before sending it to the trunks.</p> <p>Match pattern: The dialed number will be compared against the prefix + this match pattern. Upon a match, the match pattern portion of the dialed number will be sent to the trunks.</p> <p>CallerID: If CallerID is supplied, the dialed number will only match the prefix + match pattern if the CallerID has been transmitted matches this.</p> <p>When extensions make outbound calls, the CallerID will be their extension number and NOT their Outbound CID.</p> <p>The above special matching sequences can be used for CallerID matching similar to other number matches.</p>
Set the Caller ID Name to	What caller ID name would you like to set before sending this call to the endpoint.
Set the Caller ID Number to	What caller ID number would you like to set before sending this call to the endpoint.
Forward Number	This number will be sent to target PBX or SIP Server as a DID number for inbound rule settings.
Custom Context	Custom the context of dialing rules.

Random Delay	Randomly obtain any value within the threshold interval.
Failover Call Through Number	The gateway will attempt to send the call out each of these in the order you specify.

5.2 Groups

Sometimes you want to make a call through one port, but you don't know if it is available, so you have to check which port is free. That would be troublesome. But with our product, you don't need to worry about it. You can combine many Port or SIP to groups. Then if you want to make a call, it will find available port automatically. For the "Ascending" policy, if 2 or more port members are selected, it will use the first available port to call/access the call. In this case, if the gsm-1.1 is available, it will always use the gsm-1.1 call, otherwise, it will use gsm-1.2, and so on.

Figure 5-2-1 Routing Groups

Routing Groups	
Group Name:	<input type="text"/>
Type:	MODULE ▾
Policy:	Ascending ▾
Members	NO. <input type="checkbox"/> All 1 <input checked="" type="checkbox"/> Itc-1.1 2 <input checked="" type="checkbox"/> Itc-1.2 3 <input checked="" type="checkbox"/> Itc-1.3 4 <input checked="" type="checkbox"/> Itc-1.4 5 <input checked="" type="checkbox"/> gsm-2.5 6 <input checked="" type="checkbox"/> gsm-2.6 7 <input checked="" type="checkbox"/> gsm-2.7 8 <input checked="" type="checkbox"/> gsm-2.8
<input type="button" value="Save"/> <input type="button" value="Apply"/> <input type="button" value="Cancel"/>	

5.3 Batch Creating rules

This page can generate multiple routing rules at the same time.

Figure 5-3-1 Batch Creating rules

Port	Sim Number	Sip Trunk	CallerID
lte-1.1	66001	10028	101
lte-1.2	66002	None	102
lte-1.3	66003	None	200
lte-1.4		None	
gsm-2.5		None	
gsm-2.6		None	
gsm-2.7		None	
gsm-2.8		None	

SIM Number: This number will be sent to target PBX or SIP Server as a DID number for inbound rule settings. If the SIM number is empty, no incoming routing is created.

The SIM number will be sent to the target PBX or SIP server as DID number, and the calling number will be set to the caller ID in the outgoing route.

Figure 5-3-2 Create an incoming route

Call Routing Rule

Routing Name:	gsm-1.12sip
Call Comes in From:	lte-1.1
Send Call Through:	10028

DISA Settings

Authentication:	OFF
-----------------	-----

Advance Routing Rule

Dial Patterns that will use this Route	(prepend <input type="text"/>) + <input type="text"/> <input type="text"/> [match pattern] / <input type="text"/> Callerid <input type="button" value="X"/>
+ Add More Dial Pattern Fields	

Time Patterns that will use this Route	Time to start: <input type="text"/> : <input type="text"/> Time to finish: <input type="text"/> : <input type="text"/> Week Day start: <input type="text"/> Week Day finish: <input type="text"/> Month Day start: <input type="text"/> Month Day finish: <input type="text"/> Month start: <input type="text"/> Month finish: <input type="text"/>
+ Add More Time Pattern Fields	

Change Rules

Set the Caller ID Name to	<input type="text"/>
Set the Caller ID Number to	<input type="text"/>
Forward Number	66001
Custom Context	<input type="text"/>
Random Delay:	OFF

Failover Call Through Number

Add a Failover Call Through Provider	
--------------------------------------	--

Figure 5-3-3 Create an outgoing route

Call Routing Rule

Routing Name:	sip2gsm-1.1
Call Comes in From:	10028
Send Call Through:	lte-1.1

DISA Settings

Authentication:	OFF
-----------------	-----

Advance Routing Rule

Dial Patterns that will use this Route	(prepend <input type="text"/>) + <input type="text"/> <input type="text"/> [match pattern] / <input type="text"/> Callerid <input type="button" value="X"/>
+ Add More Dial Pattern Fields	

Time Patterns that will use this Route	Time to start: <input type="text"/> : <input type="text"/> Time to finish: <input type="text"/> : <input type="text"/> Week Day start: <input type="text"/> Week Day finish: <input type="text"/> Month Day start: <input type="text"/> Month Day finish: <input type="text"/> Month start: <input type="text"/> Month finish: <input type="text"/>
+ Add More Time Pattern Fields	

5.4 MNP Settings

Mobile Number Portability allows switching between mobile phone operators without changing the mobile number.

Figure 5-4-1 MNP Settings

The screenshot shows the 'MNP Settings' configuration page. It includes fields for 'MNP Check Enable' (set to 'ON'), 'MNP URL' (containing a password string), 'MNP Timeout' (set to 30), and 'Manipulation Choice' (with two radio button options: 'Route calls after manipulation' and 'Route calls before manipulation').

The URL is displayed as a password string. So please enter the URL in the format below and check if it is correct. After confirming, copy it to the gateway.

Here is an example of the MNP url: <https://s1.bichara.com.br:8181/chkporta.php?user=832700&pwd=sdsfdg&tn=8388166902>. The 8388166902 is the outgoing phone number, The outgoing number in the url should be replaced by a variable \${num}.

When configuring MNP url, it should be replaced with \${num}, Then paste:[https://s1.bichara.com.br:8181/chkporta.php?user=832700&pwd=sdsfdg&tn=\\${num}](https://s1.bichara.com.br:8181/chkporta.php?user=832700&pwd=sdsfdg&tn=${num}).

5.5 Routing Blacklist

Figure 5-5-1 Routing Blacklist Settings

The screenshot shows the 'Routing Blacklist' configuration page. It includes a 'Enable Blacklist' switch (set to 'ON') and a table for dial patterns. The table has one row with 'Number1' set to '4008006235'. There is also a 'Save' button at the bottom.

Blacklists are used to add a phone number to the blacklist or to remove a phone number from the blacklist. After opening the blacklist routing, in the incoming mode, if the calling number is in the blacklist, it will be routed to hangup() to end the call.

6. SMS

6.1 General

You can choose enable SMS Received, SMS Local Stored and SMS Status Report or not.


Figure 6-1-1 SMS Settings

General	⚠ Turn on SMS Received switch before you enable Query Balance, Query Number, SMS Local Stored, SMS to Email or SMS to HTTP!
SMS Received:	ON
SMS Local Stored:	ON
SMS Status Report:	ON

Sender Options

You can change sender options here, include resend and the time of resend.

Figure 6-1-2 Sender Options



Sender Options	
Resend Failed Message:	0
Repeat Same Message:	1
Verbose:	3

Table 6-1-1 Description of Sender Options

Options	Definition
Resend Failed Message	The times that you will attempt to resend your failed message.
Repeat Same Message	The times that you will resend the same message.
Verbose	Verbose level of sending message.

SMS to Email

This is a tool that makes it available for you to email account to transmit th

e SMS to other email boxes. The following settings realize that received SMS through openvpnvoip@gmail.com transmit to openvpnvoip@yahoo.com.cn, openvpnvoip@hotmail.com and support@openvox.cn.

Figure 6-1-3 SMS to Email

SMS to Email	
Enable:	<input checked="" type="checkbox"/> ON
SMTP Server:	OTHER ▾
Email Address of Sender:	openvpnvoip@gmail.com
Domain:	smtp.gmail.com
SMTP Port(default 25):	587
SMTP User Name:	openvpnvoip@gmail.com
SMTP Password:	*****
TLS Enable:	<input checked="" type="checkbox"/> This option allows the authentication with certificates.
Destination Email Address 1:	openvpnvoip@yahoo.com.cn
Destination Email Address 2:	openvpnvoip@hotmail.com
Destination Email Address 3:	support@openvox.cn
Title:	support
Content:	we can offer 24 hour's support

Table 6-1-2 Types of E-mail Box

E-mail Box Type	SMTP Server	SMTP Port	SMTP Security Connectivity
Gmail	smtp.gmail.com	587	✓
Hotmail	smtp.live.com	587	✓
Yahoo!	smtp.mail.yahoo.co.in	587	✗
e-mail	smtp.163.com	25	✗

Table 6-1-3 Definition of SMS to E-mail

Options	Definition
Enable	When you switch on, the following options are available, otherwise, the following options are unavailable.

Email Address of Sender	To set the email address of an available email account. For example: <u>openvpnvoip@gmail.com</u> .
Domain	To set outgoing mail server. For example: smtp.gmail.com.
SMTP Port	To set the port number of outgoing mail server. (Default is 25)
SMTP User Name	The login name of your existing email account. The login name of your existing email account. This option might be different from your email address. Some email client doesn't need the email postfix.
SMTP Password	The password to login your existing email.
TLS Enable	When you choose Yahoo and 163 free e-mails, this option is not available.
SMTP Server	To set outgoing mail server. For example: mail.openvox.cn.
Destination Email Address1	The first email address to receive the inbox message.
Destination Email Address2	The second email address to receive the inbox message.
Destination Email Address3	The third email address to receive the inbox message.

SMS Control

It allows the endpoint to send some specific KEY WORDS and corresponding PASSWORD in response to operate the gateway. SMS is case-sensitive. In default, this function is disabled.

Figure 6-1-4 SMS Control

SMS Control	
Enable:	<input checked="" type="checkbox"/> ON
Password:	admin
SMS Formats:	reboot system PASSWORD reboot asterisk PASSWORD restore config PASSWORD get info PASSWORD
SMS Inbox Auto clean:	<input checked="" type="checkbox"/> ON maxsize: 20MB

For example, SMS control password is 123456 which has nothing to do with the login password, you can send “get info 123456” to the module’s phone number to get your gateway’s IP information.

Table 6-1-4 Definition of SMS Control

Options	Definition
Enable	ON (enable), OFF (disable).
Password	The password to confirm that SMS makes the gateway rebooted, shut down, restored configuration files and get info on this gateway.
SMS Format	For example, the message formats: reboot system PASSWORD : To reboot your whole gateway (The PASSWORD is referring to the PASSWORD you set up from option “PASSWORD” above). Reboot asterisk PASSWORD : To restart your gateway core. restore config PASSWORD: To reset the configuration files back to the default factory settings. Get info PASSWORD: To get your gateway IP address.
SMS inbox Auto clean	Switch on: When the size of the SMS inbox record file reaches the max size, the system will cut a half of the file.

	<p>New record will be retained.</p> <p>Switch off: SMS record will remain, and the file size will increase gradually. Default on, max size = 20 MB.</p>
--	---

HTTP to SMS

Figure 6-1-5 HTTP to SMS Settings

Table 6-1-5 Definition of HTTP to SMS

Options	Definition
Enable	ON (enable), OFF (disable).
Enable CORS	ON (enable), OFF (disable).
Allow Access Origin Domain	Allow source domain names or IPs that can be accessed across domains.
URL	<p>The URL for send sms.</p> <p>Username: the login username for send sms.</p> <p>Password: the login password for send sms.</p> <p>Phone number: the destination telephone number.</p> <p>Message: the SMS contents.</p> <p>Port: the gsm port for send sms. For example: gsm-1.1, gsm-1.2.</p> <p>Report: the sending result report format.</p>

	Timeout: how long to wait.
--	----------------------------

SMS to HTTP

Figure 6-1-6 SMS to HTTP Settings




Table 6-1-6 Definition of SMS to HTTP

Options	Definition	Example
host	HTTP server IP address or domain.	172.16.6.171
port	HTTP server port.	80
param1	File path for receiving and processing the SMS data requests.	smsreceive.php
param2	The name of the parameter used to process the 'port' value.	port
param3	The name of the parameter used to process the 'port name' value.	port name
param4	The name of the parameter used to process the ' message ' value.	message
param5	The name of the parameter used to process the ' time ' value.	time

6.2 SMS Sender

Click the box to select the corresponding port number, fill in the target number and SMS content .Then you can send it. Different numbers should be separated by symbols: '\r', '\n', space character, semicolon and comma. After sending a text message, if the SMS status report is enabled, a detailed report of the SMS transmission will be displayed below.

Figure 6-2-1 SMS Sender

The screenshot shows the 'SMS Sender' configuration page. At the top, there's a section for selecting ports with checkboxes for 'lte-1.1', 'gsm-2.5', 'All', 'lte-1.2', 'gsm-2.6', 'lte-1.3', 'gsm-2.7', 'lte-1.4', and 'gsm-2.8'. Below that is a 'Flash SMS:' switch set to 'OFF'. A 'Load numbers from text file:' input field contains a browse button '选择文件' and a message '未选择任何文件'. Under 'Destination Number:', there's a text input field containing '10086'. A note below it says: '"; semicolon", "| vertical Bar", ", comma ", " blank ", ": colon ", ". dot " were treated as separators in Destination Number List'. In the 'Message:' section, the text 'ye' is entered. At the bottom, there are 'Action:' buttons for 'Send' and 'Stop'.

6.3 SMS Inbox

On this page, you are allowed to scan, delete, clean up, and export each port's received SMS. Also you are allowed to check messages by port, phone number, time order and message keywords.

Figure 6-3-1 SMS Inbox

Port	Phone Number	Time	Message Keywords
all		from	to
Filter Clean Filter			
Total Records: 170			
Port	Phone Number	Time	Message
gsm-7.27	10086	2019/04/02 12:03:33	【好网选移动，流量放心用！，猛戳 http://dx.10086.cn/bx1hb05 】尊敬的客户：您当前账户余额25.50元，下一个月结日为2019年04月22日。如需充值请点击 http://gd.10086.cn/cz 。【0元领副卡获赠10G流量： http://dx.10086.cn/vFvY3a 】 【中国移动】
gsm-7.25	10086	2019/04/02 12:03:32	【好网选移动，流量放心用！，猛戳 http://dx.10086.cn/bx1hb05 】尊敬的客户：您当前账户余额30.00元，下一个月结日为2019年04月05日。如需充值请点击 http://gd.10086.cn/cz 。【0元领副卡获赠10G流量： http://dx.10086.cn/vFvY3a 】 【中国移动】
gsm-7.28	10086	2019/04/02 12:03:32	尊敬的客户：您已欠费4.40元，已被停机。如需充值请点击 http://gd.10086.cn/cz 。 【中国移动】
gsm-7.26	10086	2019/04/02 12:03:32	尊敬的客户：您已欠费1.04元，已被停机。如需充值请点击 http://gd.10086.cn/cz 。 【中国移动】
lte-4.15	10086	2019/04/02 12:03:30	【好网选移动，流量放心用！，猛戳 http://dx.10086.cn/bx1hb05 】尊敬的客户：您当前账户余额23.51元，下一个月结日为2019年04月28日。如需充值请点击 http://gd.10086.cn/cz 。【0元领副卡获赠10G流量： http://dx.10086.cn/vFvY3a 】 【中国移动】
lte-4.14	10086	2019/04/02 12:03:30	【好网选移动，流量放心用！，猛戳 http://dx.10086.cn/bx1hb05 】尊敬的客户：您当前账户余额38.20元，下一个月结日为2019年04月05日。如需充值请点击 http://gd.10086.cn/cz 。【0元领副卡获赠10G流量： http://dx.10086.cn/vFvY3a 】 【中国移动】
lte-4.13	10086	2019/04/02 12:03:30	尊敬的客户：您已欠费3.60元，已被停机。如需充值请点击 http://gd.10086.cn/cz 。 【中国移动】
lte-4.15	10086055	2019/04/02 09:33:21	尊敬的客户，感谢您一直以来对我们的支持，诚邀您体验我司88元畅享套餐尊享计划优惠。此套餐优惠仅需88元，即可获得一年内每月60GB国内通用流量+2000分钟国内通话分钟数。基本相当于只需支付88元/月，即可语音流量任性用。此优惠您需要到客户办理，数量有限办完即止，赶快点击 http://dx.10086.cn/vFFD80 抢购吧。优惠活动从今起至2019年12月31日。 【中国移动】
lte-4.13	10086	2019/04/01 11:34:31	尊敬的客户：截止04.13，您的号码账户余额为0元，尚需缴费3.60元。号码现已暂停使用。支付宝自动充可享充值优惠，打开支付宝APP-充值中心-自动充办理，戳此链接马上办理： http://dx.10086.cn/duanxinl 。 【中国移动】
lte-4.13	10086	2019/04/01 11:10:54	尊敬的客户：04月01日因您账户余额不足扣取月结日所需划扣费用5.00元，月结扣费导致欠费停机，为保障您的通讯服务不受影响，请及时充值开机。支付宝自动充可享充值优惠，打开支付宝APP-充值中心-自动充办理，戳此链接马上办理： http://dx.10086.cn/duanxinl 。 【中国移动】

6.4 SMS Outbox

On this page, you are allowed to scan, delete, clean up, and export each port's received SMS. Also, you are allowed to check messages by port, phone number, time order and message keywords.

Figure 6-4-1 SMS Outbox

Port	Phone Number	Time	Message Keywords
all		from	to
Filter Clean Filter			
Total Records: 105			
Port	Phone Number	Time	Status
gsm-7.27	10086	2019-04-02 14:41:15	DELIVERD
gsm-7.28	10086	2019-04-02 14:41:00	DELIVERD
gsm-7.25	10086	2019-04-02 14:41:00	DELIVERD
gsm-3.9	10086	2019-04-02 14:41:00	DELIVERD
gsm-7.26	10086	2019-04-02 14:40:59	DELIVERD
lte-4.14	10086	2019-04-02 14:40:52	DELIVERD
lte-4.15	10086	2019-04-02 14:40:52	DELIVERD
lte-4.13	10086	2019-04-02 14:40:47	DELIVERD
lte-4.16	10086	2019-04-02 14:40:47	DELIVERD
gsm-7.25	10086	2019-04-02 14:35:55	DELIVERD

6.5 SMS Forwarding

Using this function, you can forward incoming SMS to your mobile. You can click

New Routing

button to add new routing. For example:

Figure 6-5-1 SMS Forwarding

Routing Name	Type	Policy	From_Members	To_Members	To Number	Actions
forward	module	ascending	Ite-1.1,Ite-1.2	Ite-1.3,Ite-1.4	13923704563	 

SMS received by Ite-1.1 and Ite-1.2, will be transferred to phone number 13923704563 through Ite-1.3 or Ite-1.4.

Figure 6-5-2 Create a Routing

Routing Groups																			
Routing Name:	forward																		
Type:	MODULE ▼																		
Policy:	Ascending ▼																		
From Members	<table><thead><tr><th>NO.</th><th></th></tr></thead><tbody><tr><td>1</td><td><input checked="" type="checkbox"/> Ite-1.1</td></tr><tr><td>2</td><td><input checked="" type="checkbox"/> Ite-1.2</td></tr><tr><td>3</td><td><input type="checkbox"/> Ite-1.3</td></tr><tr><td>4</td><td><input type="checkbox"/> Ite-1.4</td></tr><tr><td>5</td><td><input type="checkbox"/> gsm-2.5</td></tr><tr><td>6</td><td><input type="checkbox"/> gsm-2.6</td></tr><tr><td>7</td><td><input type="checkbox"/> gsm-2.7</td></tr><tr><td>8</td><td><input type="checkbox"/> gsm-2.8</td></tr></tbody></table>	NO.		1	<input checked="" type="checkbox"/> Ite-1.1	2	<input checked="" type="checkbox"/> Ite-1.2	3	<input type="checkbox"/> Ite-1.3	4	<input type="checkbox"/> Ite-1.4	5	<input type="checkbox"/> gsm-2.5	6	<input type="checkbox"/> gsm-2.6	7	<input type="checkbox"/> gsm-2.7	8	<input type="checkbox"/> gsm-2.8
NO.																			
1	<input checked="" type="checkbox"/> Ite-1.1																		
2	<input checked="" type="checkbox"/> Ite-1.2																		
3	<input type="checkbox"/> Ite-1.3																		
4	<input type="checkbox"/> Ite-1.4																		
5	<input type="checkbox"/> gsm-2.5																		
6	<input type="checkbox"/> gsm-2.6																		
7	<input type="checkbox"/> gsm-2.7																		
8	<input type="checkbox"/> gsm-2.8																		
To Members	<table><thead><tr><th>NO.</th><th></th></tr></thead><tbody><tr><td>1</td><td><input type="checkbox"/> Ite-1.1</td></tr><tr><td>2</td><td><input type="checkbox"/> Ite-1.2</td></tr><tr><td>3</td><td><input checked="" type="checkbox"/> Ite-1.3</td></tr><tr><td>4</td><td><input checked="" type="checkbox"/> Ite-1.4</td></tr><tr><td>5</td><td><input type="checkbox"/> gsm-2.5</td></tr><tr><td>6</td><td><input type="checkbox"/> gsm-2.6</td></tr><tr><td>7</td><td><input type="checkbox"/> gsm-2.7</td></tr><tr><td>8</td><td><input type="checkbox"/> gsm-2.8</td></tr></tbody></table>	NO.		1	<input type="checkbox"/> Ite-1.1	2	<input type="checkbox"/> Ite-1.2	3	<input checked="" type="checkbox"/> Ite-1.3	4	<input checked="" type="checkbox"/> Ite-1.4	5	<input type="checkbox"/> gsm-2.5	6	<input type="checkbox"/> gsm-2.6	7	<input type="checkbox"/> gsm-2.7	8	<input type="checkbox"/> gsm-2.8
NO.																			
1	<input type="checkbox"/> Ite-1.1																		
2	<input type="checkbox"/> Ite-1.2																		
3	<input checked="" type="checkbox"/> Ite-1.3																		
4	<input checked="" type="checkbox"/> Ite-1.4																		
5	<input type="checkbox"/> gsm-2.5																		
6	<input type="checkbox"/> gsm-2.6																		
7	<input type="checkbox"/> gsm-2.7																		
8	<input type="checkbox"/> gsm-2.8																		
To Number:	13923704563																		

For "Ascending" Policy, if you choose 2 or more ports members, it will use first available port to transfer SMS. For this case, if Ite-1.3 is available, it will always use Ite-1.3 to transfer SMS; otherwise, it will use Ite-1.4 to transfer SMS.

7. Network

7.1 LAN Settings

There are three types of LAN port IP: Factory, Static, and DHCP. The Factory is the default type with an IP of 172.16.98.1. This page is not editable when the LAN IPv4 type is selected as "Factory".

DNS Servers: A list of DNS IP address. Basically this info is from your local network service provider.

A reserved IP address to access in case your gateway IP is not available. Remember to set a similar network segment with the following address of your local PC.

Figure 7-1-1 LAN Settings

LAN IPv4
Interface: eth0
Type: Static
MAC: A0:98:05:0A:2D:F7
IPv4 Settings
Address: 172.16.6.108
Netmask: 255.255.0.0
Default Gateway: 172.16.0.1
DNS Servers
DNS Server 1: 8.8.8.8
DNS Server 2:
DNS Server 3:
DNS Server 4:
Reserved Access IP
Enable: <input type="checkbox"/> OFF

Table 7-1-1 Definition of LAN Settings

Options	Definition
Interface	The name of the network interface.

Type	The method to get IP: Factory: Getting IP address by Slot Number (System information to check slot number). Static: Manually set up your gateway IP. DHCP: Automatically get IP from your local LAN.
MAC Address	Physical address of your network interface.
IP Address	The IP address of your gateway.
Netmask	The subnet mask of your gateway.
Default Gateway	Default gateway IP address.

7.2 WAN Settings

There are three types of WAN port IP, Disable, Static and DHCP. DHCP is the default type. When you Choose IPv4 type is “Disable” or “DCHP”, this page is not editable.

Figure 7-2-1 WAN Settings

The screenshot shows a configuration page for the WAN IPv4 settings. At the top, there is a blue header bar with the text "WAN IPv4". Below this, there are four input fields arranged vertically. The first field has the label "Interface:" followed by the value "eth1". The second field has the label "Type:" followed by a dropdown menu containing the option "DHCP". The third field has the label "MAC:" followed by the value "00:E0:4C:36:01:8F". The entire form is contained within a light gray rectangular area.

7.3 VPN Settings

The wireless gateway provides PPTP and N2N VPN connections, which allow users to establish virtual private networks, encrypt communications, and achieve remote access.

Figure 7-3-1 PPTP VPN Settings

VPNTYPE:	PPTP VPN
PPTP VPN Settings	
Server:	172.16.8.136
Account:	
Password:	
Use MPPE:	<input checked="" type="checkbox"/>
* Connection Status:	Failed to connect
<input type="button" value="Save"/>	

Figure 7-3-2 N2N VPN Settings

VPNTYPE:	N2N VPN
N2N VPN Settings	
Enable:	ON
Server Address:	
Port:	
Local IP:	
Subnet Mask:	
User Name:	
Password:	
* Connection Status:	Failed to connect
<input type="button" value="Save"/>	

7.4 DDNS Settings

You can enable or disable DDNS (dynamic domain name server).

Figure 7-4-1 DDNS Settings


DDNS	ON
Type:	inadyn
User Name:	admin
Password:	****
Your domain:	www.internet.site.com
<input type="button" value="Save"/>	

Table 7-4-1 Definition of DDNS Settings

Options	Definition
DDNS	Enable/Disable DDNS (dynamic domain name server).
Type	Set the type of DDNS server.
Username	Your DDNS account's login name.
Password	Your DDNS account's password.
Your domain	The domain to which your web server will belong.

7.5 Toolkit

Some tools for checking network connections are provided, Ping commands and route tracking are supported in the web user interface. You can set the source/destination host address, port, and protocol to capture network packets.

Figure 7-5-1 Toolkit

7.6 Firewall Settings

Figure 7-6-1 Firewall Settings

The screenshot shows a configuration interface titled "Firewall Settings". It contains two main settings: "Firewall Enable" which is set to "ON", and "Ping Enable" which is also set to "ON". Both settings have a small switch icon next to them.

Table 7-6-1 Definition of Firewall Settings

Options	Definition
Firewall Enable	If you want to use White/Black List, and security rules, you must enable this option.
Ping Enable	Whether to enable the Ping function. If the status is OFF: disable ping, the gateway does not allow ping.

Figure 7-6-2 White/Black List Settings

The screenshot shows a configuration interface for "White List Settings" and "Black List Settings". Each section includes an "Enable" switch (set to "ON") and a "List IP Settings" input field. The "White List Settings" section has a larger input field than the "Black List Settings" section.

Table 7-6-2 Definition of White/Black List Settings

Options	Definition
White/Black List Enable	To enable White/Black list or not.
List IP	IP is separated only by "," character.

7.7 Security Rules

Figure 7-7-1 Security Rules Settings


Rule Name	Type	Protocol	IP	Port	Actions
SIP	UDP	DROP	172.16.8.0/255.255.0.0	5060:5060	
RTP	TCP	ACCEPT	172.16.8.0/255.255.0.0	10000:20000	
New Rule Submit					

Security Rules	
Rule Name:	SIP
Protocol:	UDP
Port:	5060
IP / MASK:	172.16.8.0 / 255.255.0.0
Actions:	DROP

Click "submit" button to submit and apply configuration.


If "List IP Settings" has no problem, you will see popup window like below. Please read the warning and tips carefully. And Click "Apply" button in 1 minute. If time runs out, this window will close automatically.

Figure 7-7-2 Security Rules Apply



If you see the windows like below. It means your configuration has been applied successfully.

Figure 7-7-3 Figure 7-11 Security Rules Apply



7.8 SIP Capture

You can capture the SIP packets on this page to facilitate location problems.

Figure 7-8-1 SIP Capture

The screenshot shows a 'SIP Capture' configuration window. It includes fields for 'Interface' (set to 'eth0'), 'Method-filter' (checkboxes for INVITE, OPTIONS, REGISTER, and All, with INVITE checked), and a 'Start Capture' button.

Table 7-8-1 SIP Capture Settings

Options	Definition
Interface	You can choose eth0, eth1 or eth0:0.
Method-filter	You can choose INVITE, OPTIONS, REGISTER or ALL.

8. Advances

8.1 Asterisk API

When you make “Enable” switch to “ON”, this page is available.

Figure 8-1-1 Asterisk API

General	
Enable:	<input checked="" type="button"/> ON
Port:	5038
Manager	
Manager Name:	admin
Manager secret:	NS1hPs2d
Deny:	
Permit:	
Rights	
System:	read: <input checked="" type="checkbox"/> write: <input checked="" type="checkbox"/>
Call:	read: <input checked="" type="checkbox"/> write: <input checked="" type="checkbox"/>
Log:	read: <input checked="" type="checkbox"/> write: <input checked="" type="checkbox"/>
Verbose:	read: <input checked="" type="checkbox"/> write: <input checked="" type="checkbox"/>
Command:	read: <input type="checkbox"/> write: <input checked="" type="checkbox"/>
Agent:	read: <input checked="" type="checkbox"/> write: <input checked="" type="checkbox"/>
User:	read: <input checked="" type="checkbox"/> write: <input checked="" type="checkbox"/>
Config:	read: <input checked="" type="checkbox"/> write: <input checked="" type="checkbox"/>
DTMF:	read: <input checked="" type="checkbox"/> write: <input type="checkbox"/>
Reporting:	read: <input checked="" type="checkbox"/> write: <input type="checkbox"/>
CDR:	read: <input checked="" type="checkbox"/> write: <input type="checkbox"/>
Dialplan:	read: <input checked="" type="checkbox"/> write: <input type="checkbox"/>
Originate:	read: <input type="checkbox"/> write: <input checked="" type="checkbox"/>
All:	read: <input checked="" type="checkbox"/> write: <input checked="" type="checkbox"/>

Table 8-1-1 Definition of Asterisk API


Options	Definition
Port	Network port number.
Manager Name	Name of the manager without space.
Manager secret	Password for the manager. Allowed characters: “-_<>@#0-9a-zA-Z”. Length: 4-32 characters.

Deny	If you want to deny some hosts or networks, you can use char & as separator. For example: 192.168.1.0/255.255.255.0&10.0.0.0/255.0.0.0.
Permit	If you want to permit some hosts or networks, you can use char & as separator. For example: 192.168.1.0/255.255.255.0&10.0.0.0/255.0.0.0.
System	General information about the system and ability to run system management commands, such as Shutdown, Restart, and Reload.
Call	The information about channels and the setting information of the channel in use.
Log	Logging information.
Verbose	Verbose information.
Command	Permission to run CLI commands. Write-only.
Agent	The information about queues and agents and the ability to add queue members to a queue.
User	Permission to send and receive User Event.
Config	Ability to read and write configuration files.
DTMF	Receive DTMF events. Read-only.
Reporting	The ability to get information about the system.
CDR	Call records. Read-only.
Dialplan	Receive NewExten and Varset events. Read-only.

Originate	Permission to initiate new calls. Write-only.
All	Select all or deselect all.

Please refer to the following figure to access the gateway API by telnet. 172.16.179.1 is the gateway's IP, and 5038 is its API port.

Figure 8-1-2 Telnet Access Gateway API



8.2 Asterisk CLI

On this page, you are allowed to run Asterisk commands.

Figure 8-2-1 Asterisk CLI

The screenshot shows a web-based Asterisk Command Line Interface. At the top, there's a header bar with tabs and a search bar containing the command 'gsm show spans'. Below this is a large text area labeled 'Output:' which displays the results of the command: a list of 8 GSM spans, each with its power status, provision status, and SIM card status.

Output:	
GSM span 1:	Power off, Provisioned, Down, Active, Standard
GSM span 2:	Power on, Provisioned, Up, Active, Standard
GSM span 3:	Power on, Provisioned, Undetected SIM Card, Active, Standard
GSM span 4:	Power on, Provisioned, Undetected SIM Card, Active, Standard
GSM span 5:	Power on, Provisioned, Undetected SIM Card, Active, Standard
GSM span 6:	Power on, Provisioned, Undetected SIM Card, Active, Standard
GSM span 7:	Power on, Provisioned, Undetected SIM Card, Active, Standard
GSM span 8:	Power on, Provisioned, Undetected SIM Card, Active, Standard

Command: Type your Asterisk CLI commands here to check or debug your gateway.

Notice: If you type “help” or “?” and execute it, the page will show you the shell command.

8.3 Asterisk File Editor

On this page, you are allowed to edit and create configuration files. Click the file to edit.

Figure 8-3-1 Asterisk File Editor

The screenshot shows a table listing configuration files with their sizes. At the bottom, there are navigation buttons and links for creating new files and reloading Asterisk.

File Name	File Size
asterisk.conf	275
cdr.conf	572
cdr_syslog.conf	364
chan_extra.conf	56
dnsmgr.conf	245
dsl.conf	1520
extensions.conf	120
extensions_custom.conf	0
extensions_macro.conf	5114
extensions_routing.conf	4054

1 2 3 4 > 1 / 4 go

New Configuration File | Reload Asterisk

Click **New Configuration File** to create a new configuration file. After editing or creating, you should reload Asterisk.

8.4 Internet

In order to meet the requirements of some operators Package consumption flow, we provide Internet access which can be set in batches (This function is only available on

the LTE module currently. Other hardware does not support the Internet function at this time).

Figure 8-4-1 Asterisk Internet

The screenshot shows a web-based configuration interface for managing internet connections. At the top, there's a header bar with tabs for 'Internet' and 'Timing internet'. Below it is a sub-header 'Timing internet' with a 'Close' button. A 'Timing time:' dropdown menu is set to '1 Day 0 Hour 0 Minute'. The main area is a table with columns: ID, Open, APN User Name, APN Password, APN, URL, MAX(MB), USED, Time, and Save. Each row represents an entry (Ite-1.1 to Ite-1.4) with fields for each column. At the bottom of the table are 'Save', 'Cancel', and 'Batch' buttons.

8.5 Cloud Management

SWG and VoxStack series gateways both support OpenVox Cloud Management.

Figure 8-5-1 OpenVox Cloud Management

The screenshot shows a configuration page for cloud management. It has a 'Cloud' tab at the top. Under 'Enable Cloud Service:', there's a switch set to 'ON'. Below it, 'Choose Service:' is set to 'China'. There are fields for 'Account:' and 'Password:'. A status message 'Connection Status: Cloud Service Disconnected' is shown. At the bottom are 'Save' and 'Sign up' buttons.

If your device is connected to the cloud management, the SSH and the web pages of the gateway can be accessed through the cloud management, and it can be monitored whether the device is connected to the cloud management platform. On the cloud management platform, you can also count your device model, quantity, distribution area, and so on which can provide you with efficient and excellent service and experience.

Table 8-5-1 Definition of Cloud Management

Options	Definition
Enable Cloud Service	Turn on/off the cloud management.

Choose Service	Currently supports two servers, one is China and the other is the United States.
Account	Registered account or email on the cloud management platform.
Password	The password of the account registered on the cloud management platform.
Connection Status	Whether currently connected to the cloud management platform or not.

8.6 Balance

The wireless gateway provides a balance inquiry function for users who use the SIM card in batches, it can automatically send a short message to the operator to query the current balance on the SIM card, which is convenient, fast and accurate.

Figure 8-6-1 Balance

Port	Query Type	Destination Number	Receive Number	Send Message	Matching Key	Balance	Actions
lte-1.1	SMS	10086	10086	ye	余额		
lte-1.2	SMS	10086	10086	ye	余额		
lte-1.3	SMS	10086	10086	ye	余额		
lte-1.4	SMS	10086	10086	ye	余额		
gsm-2.5	SMS	10086	10086	ye	余额		
gsm-2.6	SMS	10086	10086	ye	余额		
gsm-2.7	SMS	10086	10086	ye	余额		
gsm-2.8	SMS	10086	10086	ye	余额		

Figure 8-6-2 Balance Settings

8.7 Phone Number

The wireless gateway also provides a number inquiry function, which can automatically send a short message to the operator to query the number of the SIM card that you use currently.

Figure 8-7-1 Phone Number

Port	Query Type	Destination Number	Receive Number	Send Message	Matching Key	PhoneNumber	Actions
Ite-1.1	SMS	10086	10086	BJ	号码		
Ite-1.2	SMS	10086	10086	BJ	号码		
Ite-1.3	SMS	10086	10086	BJ	号码		
Ite-1.4	SMS	10086	10086	BJ	号码		
gsm-2.5	SMS	10086	10086	BJ	号码		
gsm-2.6	SMS	10086	10086	BJ	号码		
gsm-2.7	SMS	10086	10086	BJ	号码		
gsm-2.8	SMS	10086	10086	BJ	号码		

Figure 8-7-2 Phone Number

9. Logs

On the “Log Settings” page, you should set the related logs on to scan the responding logs page. For example, set “System Logs” on like the following, then you can turn to “System” page for system logs. Otherwise, system logs are unavailable. Other log pages are the same.

Figure 9-1 Logs Settings

Table 9-1 Definition of Logs

Options	Definition
System Logs	Whether to enable the system logs or not
Auto clean (System Logs)	Switch on: when the size of log file reaches the max size, the system will cut a half of the file and the new logs will be retained; Switch off: logs will remain, and the file size will increase gradually. The default is on, the default maxsize is 1MB.
SIP Logs	Whether to open the sip logs or not
Auto clean (SIP logs)	Switch on: when the size of log file reaches the max size, the system will cut a half of the file and the new logs will be retained;

	Switch off: logs will remain, and the file size will increase gradually. The default is on, the default maxsize is 100KB.
IAX Logs	Whether to open the IAX logs or not
Auto clean (IAX logs)	Switch on: when the size of log file reaches the max size, the system will cut a half of the file and the new logs will be retained; Switch off: logs will remain, and the file size will increase gradually. The default is on, the default maxsize is 100KB.
Call Detail Record	Show Call Detail Records for each channel.
Append IMEI	Switch on: IMEI will be appended to the CDR gsm channel in 'From' or 'To'. Switch off: No appended IMEI. The default is off.
Auto clean (Call Detail Record)	Switch on: when the size of log file reaches the max size, the system will cut a half of the file and the new logs will be retained; Switch off: logs will remain, and the file size will increase gradually. The default is on, the default maxsize is 10MB.

With the Syslog software, the gateway's logs and CDRs can be monitored and stored locally on the PC.

Figure 9-2 Logs Settings

Syslog	
Local Syslog:	ON <input checked="" type="button"/>
Server Address:	<input type="text"/>
Server Port:	<input type="text"/>
Syslog Level:	EMERG <input type="button"/>
CDR Level:	OFF <input type="button"/>

Figure 9-3 System Logs

System Logs	
[2014/01/01 00:01:21]	Power on
[2019/03/09 18:18:20]	Power on
[2019/03/09 18:22:22]	Power on
[2019/03/09 18:26:22]	Power on
[2019/03/09 18:30:21]	Power on
[2014/01/01 00:01:21]	Power on
[2019/03/09 18:38:33]	Power on
[2019/03/09 18:42:32]	Power on
[2019/03/09 18:46:27]	Power on
[2019/03/09 18:50:26]	Power on
[2014/01/01 00:01:16]	Power on
[2019/03/09 18:58:29]	Power on
[2019/03/09 19:02:32]	Power on
[2014/01/01 00:01:18]	Power on
[2019/03/09 19:10:55]	Power on
[2019/03/09 19:14:41]	Power on
[2019/03/09 19:18:46]	Power on
[2019/03/09 19:22:36]	Power on
[2019/03/09 19:26:39]	Power on
[2014/01/01 00:01:19]	Power on
[2019/03/09 19:34:48]	Power on
[2019/03/09 19:38:40]	Power on
[2014/01/01 00:01:22]	Power on
[2019/03/09 19:46:46]	Power on
[2014/01/01 00:01:20]	Power on
[2019/03/09 19:54:50]	Power on

Refresh Rate: Off ▾ Refresh Clean Up

You can easily browse your CDRs on the Web GUI, you also can delete, clean or export your CDR information.

Figure 9-4 CDR

Caller ID	Callee ID	From	To	Start Time	Duration	Result
				from	to	from to All
Filter Clean Filter						
Total Records: 33385						All
Caller ID	Callee ID	From	To	Start Time	Duration	Result
66376	1028@172.16.33.102	gsm-1.1	1028	1970-01-01 08:04:06	00:01:55	ANSWERED
66389	1028@172.16.33.102	gsm-2.2	1028	1970-01-01 08:01:50	00:01:00	ANSWERED
66390	1028@172.16.33.102	gsm-1.3	1028	1970-01-01 08:02:21	00:00:25	ANSWERED

In the new version we have enriched the LOGS display which you can see each port of the call outbound clearly.

Figure 9-5 GSM Outbound

GSM Outbound									
Port	All Calls	All Durations	Answered	Canceled	Busy	No Answer	No Dialtone	No Carrier	Other
Ite-1.1	0	0	0	0	0	0	0	0	0
Ite-1.2	0	0	0	0	0	0	0	0	0
Ite-1.3	0	0	0	0	0	0	0	0	0
Ite-1.4	0	0	0	0	0	0	0	0	0
gsm-2.5	0	0	0	0	0	0	0	0	0
gsm-2.6	0	0	0	0	0	0	0	0	0
gsm-2.7	0	0	0	0	0	0	0	0	0
gsm-2.8	0	0	0	0	0	0	0	0	0
Total	0	0	0	0	0	0	0	0	0